Inner Tracker Excercise

Antonio Cassese, Mauro Dinardo Part of this work is based on Natalia's instructions prepared for 2019 Tracker DAQ school

Documentation

- **Contemporal Contemporal Conte**
- **Content of the setting twiki:** https://twiki.cern.ch/twiki/bin/viewauth/RD53/RD53ATesting
- Middleware repository: <u>https://gitlab.cern.ch/cms_tk_ph2/Ph2_ACF/-/tree/daqSchool2021</u>
- **>** Firmware download: <u>https://gitlab.cern.ch/cmstkph2-IT/d19c-firmware/-/releases</u>

SCC jumpers

- ➔ Necessary jumpers on SCC
 - √ IREF IO
 - ✓ VREF ADC
 - \checkmark VDD CML SEL \rightarrow VDDA
 - \checkmark VDD PLL SEL \rightarrow VDDA
 - ✓ PLL RST
 - ✓ JP PWR
- **C** LDO power mode:
 - ✓ PWR A to VINA (to the left)
 - ✓ PWR D to VIND (to the left)



IT excercise

SCC to FC7 connection



IT excercise

Middleware preparation and configuration

In Ph2_ACF create a working directory (create as much working folder as you need, for example one for each sensor you are testing or whatever)

>mkdir workingFolderSensorName < Folder name example

Copy from settings folder in Ph2_ACF the configuration file CMSIT.xml and the ASCII file in settings/RD53Files/CMSIT_RD53.txt

>cd workingFolderSensorName

>cp ../settings/CMSIT.xml .

>cp ../settings/RD53Files/CMSIT_RD53.txt .

> chmod -x CMSIT.* This is not mandatory, but I prefer not to have execution permises for configuration file only

- **>** You need to properly configure the CMSIT.xml wrt the scans/calibrations you need
- **Content** Remember to properly set the IP address has explained in FC7 setup
- **C** After firmware load, please reset the board:

>CMSITminiDAQ -f CMSIT.xml -r

C As an example see the monitoring in the next slide

IT excercise

Monitoring

For the monitoring of some parameters such as V_{DDD}, V_{DDA}, V_{REF} (see next slides), you need to switch on the monitoring by putting to one the RD53 monitoring enable flag in CMSIT.xml, as shown in figure

227	=== Monitoring parameters ===</th
228	MonitoringSleepTime: sleep for monitoring thread in milliseconds
229	> Enables
230	<monitoringsettings> monitoring</monitoringsettings>
231	<monitoring enable="1" type="RD53"> Monitoring repetition rate</monitoring>
232	<monitoringsleeptime> 1000 </monitoringsleeptime>
233	<enable name="AllVariables"> 1 </enable>
234	
235	

Characterization Then you need to run CMSITminiDAQ, for example:

>CMSITminiDAQ -f CMSIT.xml -c physics

SCC configuration (1)

- **>** Power supply (PS):
 - ✓ Suggested PS voltage 1.8V (? Better on SCC and control the voltage drop on the cables?)
 - \checkmark V_{in}D and V_{in}A are shorted on SCC (JP PWR jumper):
 - Single PS channel for both analog and digital power (you need enough current, i.e. 2 A or more)
- Two channels, one for analog and one for digital: you need to switch them on simultaneously \mathcal{V}_{DDA} , $V_{DDD} = 1.2V$:
 - \checkmark In LDO mode, once the chip has the PLL locked, it is possible to set V_{DD}s via voltage trim bits
 - ✓ You need to properly set the registers named SLDO_ANALOG_TRIM & SLDO_DIGITAL_TRIM in RD53A manual
 - ✓ In Ph2_ACF, the registers are called VOLTAGE_TRIM_ANA⁴and VOLTAGE_TRIM_DIG⁴
 - \checkmark Measure the V_{DD} with a multimeter between GND and PWR A for V_{DDA} or PWR D for V_{DDD}
 - ✓ Adjust bits until both are at 1.2V

The trimming of the voltages on the board is useful, but not strictly mandatory for the school excercise

> You should have a "both on" button or similar

5 bit registers

In order to write

CMSITminiDAQ

to run

registers you need

SCC configuration (2)

Ο I_{REF} = **4.0** μ**A**:

- ✓ Using a multimeter, measure the current on the SCC card between the two pins IREF IO (for this measurement you need to remove the jumper and measure the current between the two pins)
- $\checkmark~$ Adjust I_{REF} properly adding or removing jumpers on the 4 IREF TRIM its on the SCC
- \checkmark The higher the bit value, the higher the I_{\rm REF} current
- ✓ **Put back the jumper IREF IO!**



SCC configuration (3)

> V_{REF} = **0.9** V:

- ✓ Using a multimeter, measure the voltage on the SCC card between the VREF ADC jumper and GND (you need a jumper on VREF ADC with a probing hole in the middle, allowing you to use it as a test point even with the jumper itself)
- ✓ Adjust V_{REF} properly using MONITOR_CONFIG_BG register in the xml configuration file



SCC configuration (4) - Bias voltage

- For this exercise it is not mandatory to switch on the high voltage, but
- IF you want to bias your sensor, do it at your own risk, and at lest be sure that:
 - \checkmark You never bias the sensor with LV off (switch LV on before biasing, switch bias off before LV off)
 - ✓ Limit the maximum current of your bias voltage supplier such that you can't break your sensors
 - ✓ Bias your voltage with the right polarity and "gently" (no fast ramps and no bumps)
 - ✓ Depending on your sensor type, choose a proper value for the bias voltage
 - \checkmark Take care of all the possible sensor breaking circumstances



Latency coarse



Latency coarse



Latency_Board00_Mod00_Chip00

Latency fine

Change CMSIT_Latency.xml file, according to the previous results:



Pixel alive

- Copy CMSIT.xml in CMSIT_Scurve.xml
- **Change the file**, taking care of:



Noise

Copy CMSIT.xml in CMSIT_Noise.xml

Change the file, taking care of:



Threshold equalization

- **C** Search pixel by pixel TDAC values to equalize their thresholds
- **The configuration file is the same of the pixel alive**

>CMSITminiDAQ -f CMSIT_Scurve.xml -c threqu



Threshold adjustment

Control Searches for the global threshold to a target value in electrons

<Setting name="TargetThr">

- **Constitution** The configuration file is the same of the pixel alive
- **>** You just need to set your target threshold in electrons

>CMSITminiDAQ -f CMSIT_Scurve.xml -c thradj

➔ The value(s) reported has to be used to properly set the threshold in the xml files (all



2000 </Setting>

Scurve

C The configuration file is the same of the pixel alive (well actually we called it scurve...)

> You just need to set the range and the number of bins you want

196	<setting< th=""><th><pre>name="VCalHstart"></pre></th><th>100</th><th></th></setting<>	<pre>name="VCalHstart"></pre>	100	
197	<setting< td=""><td><pre>name="VCalHstop"></pre></td><td>600</td><td></td></setting<>	<pre>name="VCalHstop"></pre>	600	
198	<setting< td=""><td><pre>name="VCalHnsteps"></pre></td><td>50</td><td></td></setting<>	<pre>name="VCalHnsteps"></pre>	50	
199	<setting< td=""><td><pre>name="VCalMED"></pre></td><td>100</td><td></td></setting<>	<pre>name="VCalMED"></pre>	100	

>CMSITminiDAQ -f CMSIT_Scurve.xml -c scurve

- CValHstart VCalMED → First bin
- CValHstop − VCalMED → Last bin
- → VCalHnseps → Number of bins



D B(0) O(0) H(0) SCurves Chip(0)

Scurve after 2000 electrons tuning

IT excercise



Common suggestions

- Run the board reset with "CMSITminiDAQ -f CMSIT.xml -r" every time you load the firmware to the fpga with "fpgaconfig -c CMSIT.xml -i your-fw-name"
 - \checkmark Without the reset it won't work.
 - \checkmark Every time the crate/FC7 is power cycled you need to load the firmware and afterwards do the reset.
- In case you have communication problems, you can try using a different DisplayPort cable
 - ✓ For all the normal operation that are covered in school only one cable is needed: The one that goes from DP1 to DP1. The other connection are not needed
- **)** If you still have problems, you can try with the 640 Mbps firmware version.

- **If** you still have problems, you can try changing the powering:
 - \checkmark Increase the PS voltage to 2.0V. This is the maximum allowed for safe operation.
 - \checkmark If it still doesn't work, you can change the powering mode to direct powering:
 - Turn off the power supply and adjust the jumper settings: change the jumpers on the two PWR_A and PWR_D headers to VDDA and VDDD respectively
 - Following the exercise you should have them now set to VINA and VIND
 - In this mode you have to be careful as the maximum allowed voltage is 1.32V! It is suggested to power it with 1.25V. A bit higher than 1.2 V to account for some voltage drop on the cable.
 - In this direct powering you cannot do the trimming with VOLTAGE_TRIM_ANA and VOLTAGE_TRIM _DIG registers. Just skip this part.
- If you still have problems and you have more chips available, try to use a different one

WARNING!!! Changing the power type and voltages can be potentially dangerous. Please do it only if you are expert enough to understand what you are doing!

2021 CMS Tracker DAQ School