# **Bindkeys in Virtuoso Layout Suite**

This document lists the default bindkeys defined for Virtuoso Layout Suite. Bindkeys tie commonly-used commands to single keys, key combinations, or mouse sequences. They can be used to automate repetitive tasks and speed up your work.

In this document, bindkeys are arranged:

- O As a Keyboard Layout
- O By Mouse Functions
- O By Miscellaneous Keys
- By Functions

**Note:** To use bindkeys in Layout XL or Layout EXL, you must first define them in Layout XL or Layout EXL, if not already defined. Bindkeys registered earlier using the Layout Viewer are no longer supported in Layout XL or Layout EXL.

### Arranged as a Keyboard Layout

Key	
Ctrl	
Shift	
Ctrl + Shift	

Esc	F1	F2	F3	F4	F5	F6	F7	F8	F9	F10	F11	F12
Cancel a	Launch Cadence	1000	Display Save a	Toggle Partial	Display Open File	Toggle Maintain	Display DRD		Toggle Filter	1010	10.55%	10.25
Command	Help	Save	Copy Form	Select	Form	Connections	Options Form		Size		Toggle Assistants	
											Toggle Toolbars	
				Toggle Area Select Option	Fully Select Figure of Selected Set						Toggle Assistants and Toolbars	
-	+	#			+ (num eric keypad)	- (numeric keypad)	Enter (numeric keypad)			BackSpace	Delete	
Decrement stop value in a w indow	Increment stop value in a w indow	Toggle Anchor Magnifier			Set Reference Point	Set Reference Point Inactive	Add Point			Delete a Point	Delete	
	1	2	3	4	5	6	7	8	9	0		
	<u> </u>		7000			25		÷				
Tab	Q	W	E	R	Т	Υ	U	District On the last	0	Р	[	1
Set Focus to Editable Field	Display Edit Properties Form	Go to Previous View	Open Display Options Form	Create Rectangle	Тар	Yank	Undo	Display Create Instance Form	Display Create Via Form			
Display Lower Window		Close the Layout Editing Window	Toggle DRD Mode	Redraw	Zoomto Selected Area	Cycle Select Next		Cycles through Overlapping Objects to Display Info Balloons for Each Object	Select Via Stack	Display Create Shape Pin Form		
	Display Edit Cellview Properties Form	Go to Next View	Display Layout Editor Options Form	Reshape	Display Tree Form	Paste	Redo		Rotate	Create Polygon		
	Add Wire Via	Create Wire								CW Hold Width		
Α	S	D	F	G	Н	J	K	L	;	,	Return	Up Arrow
QuickAlign	Stretch	Deselect the Figure Pointed by Mouse	Z oom to Fit	Toggle Gravity	Repeat Copy	Fully Select Partially Selected Objects	Create Rulers	Display Create Label Form		Display Magnifier Options Form	Apply or Finish a Point	Pan Up
Select All	Split	Deselect all	Set Display Stop Level to The Current Edit Level	Zoomto Grid	Freeze/Unfreeze DSA	Flip Selected Figure	Toggle Keep First Name					Pan Up and Stop at Edge of Design
Select Area	Display Find/Replace Form	Create a Deselection Box	Display Hierarchy Depth 32	Display Guard Ring Form			Clear Existing Rulers					Move Cursor Up
Add Wire Via			Finish Entire Net	Gather Bus Wires			Clear Ruler in Hierarchy					Scale up magnifier by a factor of 1.25
Z	X	С	V	В	N	M			Spacebar	Left Arrow	Down Arrow	Right Arrow
Zoomln	Edit in Place	Сору	Attach or Detach a Child Object	Return to Level	Cycle Snap Mode	Move		Toggle Magnifier Repeat Paste (w hen Repeat Copy command is active)	Add Wire Via	Pan Left	Pan Dow n	Pan Right
Zoom In x2	Zoomto Edit in Place		Go to CIW	Toggle Info Balloon	Set Snap mode option: L90X First					Pan Left and Stop at the Edge of Design		Pan Right and Stop at the Edge of Design
Zoom Out x2	Descend	Chop	Toggle World View	Return	Display Enter Points Form	Merge				Move Cursor Left	Move Cursor Down	Mayo Cursor
Cycle Control Wire		Cycle Auto Drop Via Solution	Finish Wire								Scale dow n magnifier by a factor of 0.80	

# **Arranged by Mouse Functions**

Mouse-	
click/Scroll/Drawthrough	
Ctrl	
Shift	
Ctrl + Shift	

Button 1 - Left Click (LMB)	Button 2 - Scroll (MMB)	Button 3 - Right Click (RMB)	Button 4	Button 5
Select a Point	Repeat	Display Context Menu	Zoom In at Click	Zoom Out at Click
Deselect a Point			Cycle Up Wire Via Alignment	Cycle Down Wire Via Alignment
Add to Current Selection	Move Mouse Point		Pan Left/West	Pan Right/East
Zoom In	Zoom Out		Scale Magnifier or Increase Width	Scale Magnifier or Decrease Width
Button 1 - Left Double Click	Button 2 - Double Click	Button 3 - Right Double Click	Button 4 - Double Click	Button 5 - Double Click
Enter Point		Display Edit Properties Form		
Button 1 - Draw Through	Button 2 - Draw Through	Button 3 - Draw Through	Button 4 - Draw Through	Button 5 - Draw Through
Select Objects	Pan	Zoom In		
Deselect Objects				
Add to Current Selection		Zoom Out		

# **Arranged by Miscellaneous Keys**

Key	
Ctrl	
Shift	
Ctrl + Shift	

R4	R5	R6	R7	R9	R11	R13	R15
Set Cursor Movement Distance to 0.5 User Units	Set Cursor Movement Distance to 1.0 User Units	Set Cursor Movement Distance to 2.0 User Units	Pan North West	Pan North East	Pan to Design	Pan South West	Pan South East
			Pan North West and Stop at Edge of Design	Pan North East and Stop at the Edge of Design	Pan to All Edges of Design	Pan South West and Stop at Edge of Design	Pan South East and Stop at Edge of Design
			Move Cursor North West	Move Cursor North East	Move Cursor to Reference Point	Move Cursor South West	Move Cursor South East

**Note:** The R-keys are special keys available on some keyboards.

### **Arranged by Functions**

The bindkey mappings are arranged according to the following functions:

- O Using the Layout Editor Basic Commands
- O Viewing the Design
- O Using the Palette Assistant
- O <u>Using Design Rules</u>
- O Working With Hierarchical Designs
- O Creating Objects
- O Editing Objects
- O Generating Layout
- O Using the DRD Commands
- O Using the Wire Editor Commands
- O <u>Using the SPD Editor Commands</u>
- O <u>Using the SPD Preview Commands</u>

#### **Using the Layout Editor Basic Commands**

Key	
Ctrl	
Shift	
Ctrl + Shift	

Keyboard							
Esc	F1	F2	F3	F4	F5	F6	F11
Cancel a Command	Launch Cadence Help	Save	Display Save a Copy Form	Toggle Partial Select	Display Open File Form	Toggle Maintain Connections	Toggle Assistants
							Toggle Toolbars
							Toggle Assistants and Toolba
W	E	V					
Close the Layout Editing Window		Go to CIW					
	Display Layout Editor Options Form						

For more information about the Layout Editor Basic commands, see the Layout Editor Basics chapter in the Virtuoso Layout Suite XL Basic Editing User Guide.

#### **Viewing the Design**

Mouse-	
click/Scroll/Drawthrough	
Ctrl	
Shift	
Ctrl + Shift	

Keyboard									
F9	#	W	E	Т	F	I	G	,	Z
Toggle Filter Size	Toggle Anchor Magnifier	Go to Previous View	Open Display Options Form		Zoom to Fit			Display Magnifier Options Form	Zoom In
				Zoom to Selected Area		Cycles through Overlapping Objects to Display Info Balloons for Each Object	Zoom to Grid		Zoom ln x2
		Go to Next View							Zoom Out x2
X	V	В	N		Up Arrow	Left Arrow	Down Arrow	Right Arrow	
			Cycle Snap Mode	Toggle Magnifier	Pan Up	Pan Left	Pan Down	Pan Right	
Zoom to Edit in Place		Toggle Info Balloon	Set Snap mode option: L90XFirst		Pan Up and Stop at Edge of Design	Pan Left and Stop at the Edge of Design		Pan Right and Stop at the Edge of Design	
	Toggle World View					Move Cursor Left	Move Cursor Down	Move Cursor Right	
					Scale up magnifier by a factor of 1.25		Scale down magnifier by a factor of 0.80		

Mouse functions								
Button 1 - Left Click	Button 2 - Scroll	Button 4	Button 5	Button 2 - Draw Through	Button 3 - Draw Through			
		Zoom In at Click	Zoom Out at Click	Pan	Zoom In			
		Pan Left/West	Pan Right/East		Zoom Out			
Zoom In	Zoom Out							

Miscellaneous keys							
R7	R9	R11	R13	R15			
Pan North West	Pan North East	Pan to Design	Pan South West	Pan South East			
Pan North West	Pan North East	Pan to All Edges of	Pan South West	Pan South East			
and Stop at Edge	and Stop at the	Design	and Stop at Edge	and Stop at Edge			
of Design	Edge of Design	Design	of Design	of Design			

Note: For more information about the Viewing the Design commands, see the Viewing the Design chapter in the Virtuoso Layout Suite XL Basic Editing User Guide.

#### **Using the Palette Assistant**

Key	
Ctrl	
Shift	
Ctrl + Shift	

Bindkeys available when the Palette assistant is active Keyboard								
F10	F11	F12	W	0	Р	Α	S	D
Display contextual menu	Toggle Show/Hide status of all toolbars	Toggle the Show/Hide status status of all tools and toolbars	Toggle between synchronized and des ynchronized Palette states	Display Options Form	Go to previous layer set		Toggle selectability status of objects	Discard changes made during current layer set editing session
					Find Previous		Toggle selectability status of all parent and child objects	
	Toggles Show/Hide status of unselected panels					Display Save As Layer Set form	Save current layer set	
F	L	V	В	N	M	<	>	
	Toggle state of LPP validity editing mode	Toggle visibility status of objects	Display Palette section of Bindkey Editor	Go to next layer set	Toggle layer set editing mode for Palettes	Collapse all items	Expand all items	
Display Search		Toggle visibility status of all parent and child objects		Find Next				
1	2	3	4	5	6	7	8	9
		3	(=)	ibility and selectabili				
Toggle between active and inactive state of specified layer set								

Mouse functions				
Button 2 - Scroll (MMB)	Button 3 - Right Click (RMB)			
Toggle Visibility with Depth	Toggle Selectability with Depth			
setOnlyVisible with Depth	setOnlySelectable with Depth			

Note: For more information about the Palette Assistant commands, see the Palette Assistant chapter in the Virtuoso Layout Suite XL Basic Editing User Guide.

#### **Using Design Rules**

Key, Mouse-click,	
Scroll, Drawthrough	
Ctrl	
Shift	
Ctrl + Shift	

Keyboard				
T	S	K		
Тар		Create Rulers		
	Display Find/Replace Form	Clear Existing Rulers		
Rindkovs available when	n the Create Ruler comm	and is active		
Keyboard	Title Oreate Ruler collin	and is active		
Enter	Esc			
Completes the current measurement	Cancels the Create Ruler command			
Mouse functions				
Button 1 - Left Click	Button 2 - Scroll	Button 3 - Right Click	Button 4	Button 5
Adds a point	Completes the ruler without drawing	Display Context Menu	Zoom In at Click	Zoom Out at Click
Enters second point (waits to complete the measurement by allowing to place the segment by clicking button 1)	Moves the measurement segment to the clicked location		Cycle Up Wire Via Alignment	Cycle Down Wire Via Alignment
Inserts a point to make current measurement multisegment	Move Mouse Point		Pan Left/West	Pan Right/East
Zoom In	Zoom Out		Scale Magnifier or Increase Width	Scale Magnifier or Decrease Width

Note: For more information about the Design Rules commands, see the Using Design Tools chapter in the Virtuoso Layout Suite XL Basic Editing User Guide.

#### **Working With Hierarchical Designs**

Key	
Ctrl	
Shift	
Ctrl + Shift	

Keyboard				
Т	F	K	X	В
			Edit in Place	Return to Level
Display Tree Form	Display Hierarchy Depth 32		Descend	Return
		Clear Ruler in Hierarchy		

**Note:** For more information about the Hierarchical Designs commands, see the *Working With Hierarchical Designs* chapter in the *Virtuoso Layout Suite XL Basic Editing User Guide*.

#### **Creating Objects**

Key, Mouse-click, Scroll, Drawthrough	
Ctrl	
Shift	
Ctrl + Shift	

Keyboard						
+ (numeric keypad)	- (numeric keypad)	Enter (numeric keypad)	BackSpace	Return	R	1
Set Reference Point	Set Reference Point Inactive	Add Point	Delete a Point	Apply or Finish a Point	Create Rectangle	Display Create Instance Form
0	P	G	K	7	Х	N
Display Create Via Form				Display Create Label Form		
Select Via Stack	Display Create Shape Pin Form		Toggle Keep First Name			
	Create Polygon	Display Guard Ring Form				Display Enter Points Form

Mouse functions					
Button 1 - Left Click	Button 2 - Scroll	Button 1 - Left Double Click			
Select a Point	Repeat	Enter Point			
Deselect a Point					
	Move Pointer				

Miscellaneou	s keys						
R4	R5	R6	R7	R9	R11	R13	R15
Set Cursor	Set Cursor	Set Curs or			A		
Movem en t	Movement	Movement					
Distance to 0.5	Distance to 1.0	Distance to 2.0					
User Units	UserUnits	UserUnits					
			Move Cursor North West	Move Cursor North East	Move Cursor to Reference Point	Move Cursor South West	Move Cursor South East

Note: For more information about the Creating Objects commands, see the Creating Objects chapter in the Virtuoso Layout Suite XL Basic Editing User Guide.

#### **Editing Objects**

Key, Mouse-click,	
Scroll, Drawthrough	
Ctrl	
Shift	
Ctrl + Shift	

Keyboard								
F4	<b>F</b> 5	Delete	Tab	Q	R	Υ	-	+
Toggle Partial Select	Display Open File Form	Delete	Set Focus to Editable Field	Display Edit Properties Form	Create Rectangle	Yank	Decrement stop value in a window	Increment stop value in a window
			Display Lower Window		Redraw	Cycle Select Next		
Toggle Area Select Option	Fully Select Figure of Selected Set			Display Edit Cellview Properties Form	Reshape	Paste		
U	0	Α	S	D	F	G	Н	J
Undo	Display Create Via Form	Quick Align	Stretch	Deselect the Figure Pointed by Mouse	Zoom to Fit	Toggle Gravity	Repeat Copy	Fully Select Partiall Selected Objects
	Select Via Stack	Select All	Split	Deselect all	Level to The Current Edit Level	Zoom to Grid	Freeze/Unfreeze DSA	Flip Selected Figure
Redo	Rotate	Select Area	Display Find/Replace Form	Create a Deselection Box	Display Hierarchy Depth 32	Display Guard Ring Form		
С	V	М						
Сору	Attach or Detach a Child Object	Move	Toggle Magnifier Repeat Paste (when Repeat Copy command is active)					
	Go to CIW							
Chop	Toggle World View	Merge						

Mouse	Mouse								
Button 1 - Left Click	Button 2 - Scroll	Button 3 - Right Click	Button 3 - Right Double Click	Button 1 - Draw Through					
	Repeat	Display Context Menu	Display Edit Properties Form	Select Objects					
				Deselect Objects					
Add to Current Selection				Add to Current Selection					

View

Note: For more information about the Editing Objects commands, see the Editing Objects chapter in the Virtuoso Layout Suite XL Basic Editing User Guide.

#### **Generating Layout**

Key, Mouse-click, Scroll, Drawthrough	
Ctrl	
Shift	
Ctrl + Shift	

Mouse									
Button 1 - Left Click	Button 2 - Scroll	Button 3 - Right Click	Button 3 - Right Double Click	Button 1 - Draw Through					
	Transistor Width								
	Number of Folds								

Note: For more information about the layout generation and connectivity-driven commands, see the Virtuoso Layout Suite XL: Connectivity Driven Editing User Guide.

#### **Using the DRD Commands**

Key	
Ctrl	
Shift	
Ctrl + Shift	

Keyboard		_	_	_	
* (numeric keypad)	/ (numeric	F7	1	E	Н
Set object at current pointer location as a DRD Target	Remove DRD Target at current pointer location	Display DRD Options form	Enable pixel threshold when DRD Smart Snap mode is enabled		
Display DRD Options Form					
				Cycle through DRD modes	
					Compact/spread selected objects towards leftmost object in selected set
J	N	Т	U		
Compact/spread selected objects towards rightmost object in selected set	Compact/spread selected objects towards bottommost object in selected set	Compact/sprea d selected objects towards previously specified DRD targets	Compact/spread selected objects towards topmost object in selected set		

Note: Some DRD commands work in Virtuoso Layout Suite XL or GXL. For more information on these commands, refer to the Virtuoso Design Rule Driven Editing User Guide.

#### **Using the Wire Editor Commands**

Key, Mouse-click,	
Scroll, Drawthrough	
Ctrl	
Shift	
Ctrl + Shift	

Keyboard								
2	I	Р	S	D	X	С		
Finish Trunk								
		Create Wire						
	Toggle orientation of routing envelope w hen Guided Routing command is active							
			Create Stranded Wire	Start interactive Point to Point routing command	Create Bus	Cycle Auto Drop Via Solution (snapToTrack or snapTosnapPattern enabled)		
Bindkeys availa	ble:							
*When either the	e Create Wire or 0	Create Bus comm	and is active			* When Create Bus com	nmand is active	
Α	Q	E	V	Spacebar	Backspace	Z	G	
				Select Via	Backup Point			
				Cycle smart snapping targets				When digitizing a v Cycle betw een v alignment option:
Via Down the current layer	Via up the current layer	Via to Target Layers	Finish Wire/Bus	Use Current Position		Cycle through control w ires during interactive bus editing	Gather/spread or ungather/unspread bus wires	
Bindkeys availa	ble:							
* When Create W	fire command is a	ctive						
L	V	{	}	=	-			
		Toggle Auto Tw ig Mode	Cycle Taper Mode	Tw ig Increase Layer	Tw ig Decrease Layer			
Use highlighted w ire w idth to create next w ire w hen Smart Snapping is active						Disable Layer Tapping (start from palette active layer)		
							Disable Smart Snapping (start from cursor position)	

Bindkeys available:								
* When Create St	* When Create Stranded Wire command is active							
1 2 3 4								
Increase Number of Strands	Decrease Number of Strands	Increase spacing between strands	Decrease spacing between strands					
				Slide Mode hold				

Mouse	Mouse									
Button 2 - Mouse Wheel	Button 2 - Button 2 - Mouse Wheel Up Down		Button 4	Button 5						
	Zoom In	Zoom Out								
Cycle Wire/Via Alignment	Pan Up	Pan Down	Cycle Up Wire Via Alignment	Cycle Down Wire Via Alignment						
	Pan Left	Pan Right								
	Width Increase	Width Decrease								
Button 2 - Scroll (MMB)										
Rotate Via Cuts										
Rotate Via Enclosures										

Note: Some Wire Editor commands work only in Virtuoso Layout Suite XL or higher tiers. For more information on these commands, refer to the Virtuoso Space-based Router User Guide.

#### **Using the SPD Editor Commands**

Key, Mouse-click,	
Scroll, Drawthrough	
Ctrl	
Shift	
Ctrl + Shift	

Keyboard									
Esc	F1	F2	F5	Return	Up Arrow	Down Arrow	Left Arrow	Right Arrow	BackSpace
Cancel a Command	Launch SPD Help	Display Save SPD Design Form	Display Load SPD Design Form	Apply or Finish a Point	Pan Up	Pan Down	Pan Left	Pan Right	Delete a Point
					Pan Up and Stop at Edge of Design	Pan Down and Stop at the Edge of Design	Pan Left and Stop at the Edge of Design	Pan Right and Stop at the Edge of Design	
Tab	W	E	R	T	Υ	U	0	Α	D
Set Focus to Editable Field		Display SPD Options Form	Reset Placement			Undo	Fold	Align	Deselect the Figure Pointed by Mouse
Display Low er	Close the Current	Edit Stack	Redraw	Zoom to Selected	Cycle Select Next	Display Check or		Select All	Deselect all
						Redo		Unalign	Create a Deselection
								Check Align	Add Dummy
F	G	_	K	L	Z	С	V	В	N
Zoom to Fit	Generate Layout			Cycle Display of Flight Lines	ZoomIn	Generate Chained Devices	Preview	Abut	Backannotate Active Dummies
	Zoom to Grid	Flip Selected Figure (Horizontal)	Stack		Zoom In (1.25)		Go to GW		
		Flip Vertical	Unstack		Zoom Out (.8)		Toggle Free Size Mode	Unabut	Backannotate Selected Dummies
P	S	M				_			

Permute	Split Fingered Devices				
Mouse					
Button 1 - Left Click (LMB)	Button 2 - Scroll (MMB)	Button 4	Button 5		
Select a Point	Repeat	Zoom In at Click	Zoom Out at Click		
Deselect a Point		Pan Up/North	Pan Down/South		
Add to Current		Pan Left/West	Pan Right/East		
Zoom In	Zoom Out				
Button 1 - Draw	Button 2 - Draw	Button 3 - Draw			
Through	Through	Through			
Select Objects	Pan	Zoom In			
Deselect Objects					
Add Selected Box		Zoom Out			
Button 1 - Down	Button 2 - Down		•		
Zoom in	Zoom out				

Swap

Pack

Miscellaneous keys				
R7	R9	R11	R13	R15
Pan North West	Pan North East	Pan to Design	Pan South West	Pan South East
Pan North West and	Pan North East and	Dan to All Edges of	Pan South West and	Pan South East and
Stop at Edge of	Stop at the Edge of	Pan to All Edges of	Stop at Edge of	Stop at Edge of
Design	Design	Design	Design	Design

Smart Move

Note: For more information about the SPD Editor Commands, see the Virtuoso Symbolic Placement of Devices User Guide.

#### **Using the SPD Preview Commands**

Key, Mouse-click, Scroll, Drawthrough	
Ctrl	
Shift	
Ctrl + Shift	

Keyboard								
Esc	F1	Up Arrow	Down Arrow	Left Arrow	Right Arrow	BackSpace	Tab	Return
Cancel a Command	Launch SPD Help	Pan Up	Pan Dow n	Pan Left	Pan Right	Delete a Point	Set Focus to Editable Field	Apply or Finish a Point
		Pan Up and Stop at Edge of Design	Pan Dow n and Stop at the Edge of Design	Pan Left and Stop at the Edge of Design	Pan Right and Stop at the Edge of Design		Display Low er Window	
W	E	R	T	Y	U	L	P	A
Go to Previous View	Open Display Options Form				Undo		Pack	Toggle Abstract Display
Close the Preview Window		Redraw	Zoom to Selected Area	Cycle Select Next	Display Check or Update Form	Cycles through Overlapping Objects to Display Info Balloons for Each Object		Select All
Go to Next View					Redo			
D	F	G	K	Z	V	В	M	
Deselect the Figure Pointed by Mouse	Zoom to Fit	Generate Layout	Create Rulers	Zoom In			Move Tracks	
Deselect all		Zoom to Grid	Clear Ruler	Zoom In (1.25)	Go to CIV	Toggle Info Balloon		•
Create a Deselection Box				Zoom Out (.8)				

Mouse			
Button 1 - Left Click (LMB)	Button 2 - Scroll (MMB)	Button 4	Button 5
Select a Point	Repeat	Zoom In at Click	Zoom Out at Click
Deselect a Point		Pan Up/North	Pan Dow n/South
Add to Current Selection		Pan Left/West	Pan Right/East
Zoom In	Zoom Out		
Button 1 - Draw	Button 2 - Draw	Button 3 - Draw	
Through	Through	Through	
Select Objects	Pan	Zoom In	
Deselect Objects			
Add Selected Box		Zoom Out	
Button 1 - Down	Button 2 - Down		<u> </u>
Zoom in	Zoom out	1	

Miscellaneous keys				
R7	R9	R11	R13	R15
Pan North West	Pan North East	Pan to Design	Pan South West	Pan South East
Pan North West and Stop	Pan North East and Stop	Pan to All Edges of	Pan South West and Stop	Pan South East and Stop
at Edge of Design	at the Edge of Design	Design	at Edge of Design	at Edge of Design

Note: For more information about the SPD Preview Commands, see the Virtuoso Symbolic Placement of Devices User Guide.