
# Transistor layout: 250 – 28 nm, FinFETs

Eva Vilella
University of Liverpool
vilella@hep.ph.liv.ac.uk


## **ENIAC (1946 – 1954)**

### **ELECTRONIC NUMERICAL INTEGRATOR AND COMPUTER**









- 17,468 vacuum valves
- 27,000 Kg
- $-450 \text{ m}^3$
- 174 kW
- It had extremely high costs



### **Birth of Microelectronics**

1947

is considered the date of birth of Microelectronics

W. Shockley

J. Bardeen

W. Brattain


They discovered the transistor effect in Germanium

They invented the Bipolar Junction Transistor (BJT)




### **First transistor**


- Original device
  - Bipolar transistor
  - Germanium N
  - 3 electrodes
  - 2 contacts metal-semiconductor like those used for rectifiers and another large area at the base



## **Integrated circuit**



- J. Kilby, Texas Instruments, 1958
- Circuit with transistors connected by metallic wires (by hand)




- R. N. Noyce, Fairchild Semiconductors, 1959
- First monolithic integrated circuit with devices isolated by reverse biased PN junctions and interconnected with aluminium lines

## Planar technology – 1958

- Process to produce a large number of devices simultaneously on a wafer
  - Diffusion, oxidation, deposition, photolithography
- Reduced cost
- Birth of Silicon Valley
  - Fairchild Semiconductors (1957)
  - Intel (1970)

- ...




## First applications

- 1961 Fairchild Micrologic devices were designed into the AC Spark Plug MAGIC and Martin MARTAC 420 computers, but NASA's Apollo Guidance Computer (AGC) was the most significant early project. Designed by MIT in 1962 and built by Raytheon, each system used about 4,000 "Type-G" (3-input NOR gate) circuits. Consuming 200,000 units at \$20-30 each, the AGC was the largest user of ICs through 1965.
- 1962 Texas Instruments won a contract from the Autonetics Division of North American Aviation to design 22 custom circuits for the Minuteman II missile guidance system.
  - The Minuteman project by 1965 overtook NASA's Apollo procurement as the largest single consumer of integrated circuits.



### **MOS** transistors

- Many failed attempts at achieving a field effect device system
  - A capacitor-type device to modulate the carrier concentration in a semiconductor
  - The problem was the existence of too many shallow states, which prevented an electric field on the surface of the semiconductor
  - SiO<sub>2</sub> reduces the concentration of shallow states
- 1960 M. M. Atalla and D. Khang fabricate the first MOSFET (Metal-Oxide-Semiconductor Field-Effect Transistor)
- Comparison MOSFET bipolar
  - Less power consumption to control the same current
  - Less area
  - Allows for larger complexity
  - Slower










## Microprocessors and memories

- MOSFETs offered large potential
- 1970 R. Noyce, G. Moore and A. Grove left Fairchild and started Intel
  - 1970 They presented the first semiconductor chip (a memory)
    - o 1k DRAM
    - Basic cell consisted of 3 transistors
    - pMOS technology only
  - 1971 F. Faggin and E. Hoff, from Intel, fabricated the first 4004 microprocessor
    - 4 bits
    - 45 instructions
    - pMOS technology only
    - o 3.6 mm x 2.8 mm
    - 2,3000 transistors
  - (4004 microprocessor + memory + I/O chip + clock = computer )

### **Evolution of microprocessors**







**Pictures** not to scale

First μP 4004 (1971) **2,300 gates** 

275,000 gates

μP 80386 (1984) μP Pentium III (1999) 9,500,000 gates

The invention of the integrated circuit was a revolution as humankind discovered the technology to produce electronic circuits in mass volumes

### **Evolution**


- Race to increase the complexity of integrated circuits since the 1970s
  - Faster microprocessors
  - More complex memories

Moore's law (1965) → The number of transistors in a dense integrated circuit (IC) doubles about every two years

#### Moore's Law – The number of transistors on integrated circuit chips (1971-2018)



Moore's law describes the empirical regularity that the number of transistors on integrated circuits doubles approximately every two years. This advancement is important as other aspects of technological progress – such as processing speed or the price of electronic products – are linked to Moore's law.



Data source: Wikipedia (https://en.wikipedia.org/wiki/Transistor\_count)
The data visualization is available at OurWorldinData.org. There you find more visualizations and research on this topic.

Licensed under CC-BY-SA by the author Max Roser.







## Today's applications

























### **Device structure**

### **MOSFET = Metal-Oxide-Semiconductor Field-Effect Transistor**




Figure 1: Physical structure of an NMOS transistor: (a) perspective view, (b) cross-section.

### **Device structure**

two *n*-type doped regions (drain, source)

layer of SiO<sub>2</sub> separates source and drain





Figure 1: Physical structure of an NMOS transistor: (a) perspective view, (b) cross-section.

## **Symbols**




There are four terminals:

drain (D), gate (G), bulk (B), and source (S).

#### Zero Gate Voltage


- With zero voltage applied to gate, two back-to-back diodes exist in series between drain and source.
- "They" prevent current conduction from drain to source when a voltage  $v_{DS}$  is applied.
- Yielding very high resistance (10<sup>12</sup>ohms)



Physical structure of MOSFET


#### Creating a Channel for Current flow

- Q: What happens if (1) source and drain are grounded and (2) positive voltage is applied to gate?
- **step #1:**  $v_{GS}$  is applied to the gate terminal, causing a positive build up of positive charge along metal electrode.
- step #2: This "build up" causes free holes to be repelled from region of p-type substrate under gate.



**Figure 2:** NMOS transistor with a positive voltage applied to the gate. An *n* channel is induced at the top of the substrate beneath the gate.


- Creating a Channel for Current flow
  - Q: What happens if (1) source and drain are grounded and (2) positive voltage is applied to gate? Refer to figure to right.
  - step #3: This "migration" results in the uncovering of negative bound charges, originally neutralized by the free holes
  - step #4: The positive gate voltage also attracts
     electrons from the n<sup>+</sup> source and drain regions into the channel.




**Figure 2:** NMOS transistor with a positive voltage applied to the gate. An *n* channel is induced at the top of the substrate beneath the gate.


- Creating a Channel for Current flow
  - Q: What happens if (1) source and drain are grounded and (2) positive voltage is applied to gate?
  - step #5: Once a sufficient number of "these" electrons accumulate, an n-region is created...
    - ...connecting the source and drain regions
  - step #6: This provides path for current flow between D and S.


this induced channel is also known as an inversion layer



**Figure 2:** NMOS transistor with a positive voltage applied to the gate. An *n* channel is induced at the top of the substrate beneath the gate.










$$I_{D} = \frac{\mu_{n} C_{ox}}{2} \frac{W}{L} [2(V_{GS} - V_{T0}) V_{DS} - V_{DS}^{2}]$$

$$I_{D}(sat) = \frac{\mu_{n} C_{ox}}{2} \frac{W}{L} (V_{GS} - V_{T0})^{2}$$







**Cut-off region** 

Linear region

$$V_{DS} \le V_{GS} - V_{T}$$

$$I_{D} = \frac{\mu_{n} C_{ox}}{2} \frac{W}{L} [2(V_{GS} - V_{T0}) V_{DS} - V_{DS}^{2}]$$

$$I_D = k'_n W/L [(V_{GS} - V_T)V_{DS} - V_{DS}^2/2]$$

$$k'_n = \mu_n C_{ox} = \mu_n \varepsilon_{ox} / t_{ox}$$
 Transconductance

$$k_n = k'_n W/L$$


Saturation region  $V_{DS} \ge V_{GS} - V_{T}$ 


$$V_{DS} \ge V_{GS} - V_{T}$$


$$I_D(sat) = \frac{\mu_n C_{ox}}{2} \frac{W}{L} (V_{GS} - V_{T0})^2$$

$$I_D = k'_n/2 W/L [(V_{GS} - V_T)^2]$$

**Opera** 








$$I_D = k'_n/2 W/L [(V_{GS} - V_T)^2]$$

$$I_D' = I_D(1 + \lambda V_{DS})$$




#### λ Channel length modulation


 $\rightarrow$   $V_{ds}$ 

22

$$I_{D}(sat) = \frac{\mu_{n} C_{ox}}{2} \frac{W}{L} (V_{GS} - V_{T0})^{2} (1 + \lambda V_{DS})$$

## **Capacitances**








 $C_{db}$ ,  $C_{sb}$  -> Junction capacitances

## **Capacitances**

#### b. Gate - Channel








$C_{gb} = 0$
$C_{gs} = (1/2) C_{ox} W L$
$C_{gd} = (1/2) C_{ox} W L$

$$C_{gb} = 0$$

$$C_{gs} = (2/3) C_{ox} W L$$

$$C_{gd} = 0$$


Capacitance	Cut-off	Linear	Saturation
C <sub>gb</sub> (total)	$C_{ox}WL$	0	0
C <sub>gd</sub> (total)	$0 + C_{ox}WL_{D}$	$0.5C_{ox}WL + C_{ox}WL_{D}$	$0 + C_{ox}WL_{D}$
C <sub>gs</sub> (total)	$_{\mathrm{cox}}^{0}WL_{_{\mathrm{D}}}$	$0.5 { m C}_{ m ox} { m WL} + { m C}_{ m ox} { m WL}_{ m D}$	(2/3)C <sub>ox</sub> WL + C <sub>ox</sub> WL <sub>D</sub>



## **TID effects – Consequences – Leakage current**

Increase of leakage current

The leakage current in NMOS is due to the accumulation of defects in the lateral Shallow Trench Isolation (STI) oxide




F. Faccio, Radiation effects in CMOS technologies for the LHC upgrades



## **TID effects – Consequences – Leakage current**

Increase of leakage current




Leakage current also appears between adjacent n-type diffusions

L. Chen, Radiation tolerant design with 0.18-micron CMOS technology, PhD thesis

## **TID effects – Consequences – Leakage current**

Increase of leakage current

In PMOS both type of defects increase the threshold of the parasitic lateral transistor, and no leakage current can be observed




F. Faccio, Radiation effects in CMOS technologies for the LHC upgrades




### **Enclosed Layout Transistors**

Source-Drain leakage is eliminated by the Enclosed Layout Transistor (ELT)...




Inter-diffusion leakage is eliminated by p+ guard rings...



F. Faccio, Radiation effects in CMOS technologies for the LHC upgrades






channel underneath the poly of the opposite type remains present and can be

upgrades






### Planar nMOS vs FinFET





M. Campbell & F. Faccio, Future ASIC technologies in HEP experiments

### **FinFETs**

- Most commercial fabs have migrated to FinFETs below 20-nm gate length feature sizes
- FinFETs exhibit improved electrostatic control of the channel and improved reliability compared to equivalent scaled planar CMOS







T. Hook, FDSOI Conference, Taiwan, 2013


M. Campbell & F. Faccio, Future ASIC technologies in HEP experiments





## FinFET processing technology


- Increasing processing complexity
- More challenging lithography
  - Quad patterning
  - Soon EUV
- Line edge roughness
- Isolation steps
  - STI
  - CSD/SSRW




A. Yagishita (Toshiba), SOI Short Course (2009)



## FinFET – Advantages / challenges






M. Campbell & F. Faccio, Future ASIC technologies in HEP experiments





## FinFET – Design

- More drive current for given footprint
- Quantized channel width
  - Challenge for logic & SRAM
  - OK for analog, enough  $g_m$  granularity
- Less DIBL  $\rightarrow$  better  $r_{out}$ ,  $3 \times$  intrinsic gain
- Essentially no body effect (ΔV<sub>T</sub> < 10mV)</li>
- Higher R<sub>s</sub> & R<sub>d</sub> spreading resistance
- Lower C<sub>j</sub> but higher C<sub>gd</sub> & C<sub>gs</sub> coupling
- Higher R<sub>well</sub> (R<sub>diode</sub>, latch-up)
- Mismatch depends on fin geometry, MG grains, gate density, stress, less on RDF



Sheu, TSMC [18] Hsueh et al., TSMC [19]

Slide courtesy of Alvin Loke, Qualcomm







# Thank you for your attention

