



Simple sources and preprocessor

Outline

1. Simple source definition

- Definition of simple beams
 - Beam parameters
 - Beam visualisation
 - Beam rotation
- Volumetric sources
- Multiple Beam Spots
- Further possibilities

2. The FLUKA preprocessor

1. Simple sources

BEAM & **BEAMPOS** cards | Visualisation | Volumetric sources | Multiple Beam Spots

Required cards

- In the *Basic input & Flair introduction* lecture we already saw two cards related to defining a beam in FLUKA, namely the **BEAM** and **BEAMPOS** cards:

BEAM

Δp : Flat ▼
Shape(X): Rectangular ▼

Beam: Momentum ▼

Δp :
 Δx :

p :

$\Delta\phi$: Flat ▼

Shape(Y): Rectangular ▼

Part: ▼

$\Delta\phi$:
 Δy :

BEAMPOS

x :
COSX:

y :
cosy:

z :
Type: POSITIVE ▼

The BEAM card

☀ **BEAM**

Δp : Flat ▼

Shape(X): Rectangular ▼

Beam: Momentum ▼

Δp :

Δx :

p:

$\Delta\phi$: Flat ▼

Shape(Y): Rectangular ▼

Part: ▼

$\Delta\phi$:

Δy :

- The **BEAM** card allows to specify the following parameters:
 - Particle type
 - Momentum or kinetic energy
 - Momentum distribution
 - Angular distribution
 - Shape in the X-Y plane

The BEAM card: particle type

☀ **BEAM**

Δp : Flat ▼

Shape(X): Rectangular ▼

Beam: Momentum ▼

Δp :

Δx :

p:

$\Delta\phi$: Flat ▼

Shape(Y): Rectangular ▼

Part: ▼

$\Delta\phi$:

Δy :

Select particle type from the dropdown menu

Default particle: **PROTON**

Non-standard particles:

- **HEAVYION**: Ion beams heavier than ^4He – Requires a **HI-PROPE** card.
- **ISOTOPE**: Radioactive isotope sources – Requires the **HI-PROPE** and **RADDECAY** cards.
See the *Radiation Protection calculations* lecture

The BEAM card: momentum/energy definition

* BEAM

Δp : Flat ▼
Shape(X): Rectangular ▼

Beam: Momentum ▼ p:
 Δp : $\Delta\phi$: Flat ▼
 Δx : Shape(Y): Rectangular ▼

Part: ▼
 $\Delta\phi$:
 Δy :

Select **Momentum** or **Energy** from the dropdown menu

Enter the **value** in the input field next to it

Default value: 200 [GeV/c]

Note: In the case of advanced sources, setting the momentum slightly higher than the maximum momentum used in those sources is **crucial**, since this value is used to initialise the cross section data tables.

(See the *Advanced topics* lecture and FLUKA Advanced Course)

The BEAM card: momentum and angular distributions

☀ **BEAM** Beam: Momentum ▼ p: Part: ▼

Δp : Flat ▼	Δp :	$\Delta \phi$: Flat ▼	$\Delta \phi$:
Shape(X): Rectangular ▼	Δx :	Shape(Y): Rectangular ▼	Δy :

Momentum distribution types:

- **Flat**: Full width of a rectangular **momentum** distribution centred at beam momentum [GeV/c]
- **Gaussian**: FWHM of a Gaussian **momentum** distribution [GeV/c]

IMPORTANT: This is always momentum distribution, even if **Energy** was selected

Angular distribution types:

- **Flat**: Full width of a rectangular angular distribution centred at the beam axis [mrad]
- **Isotropic**: Isotropic distribution
- **Gaussian**: FWHM of a Gaussian angular distribution centred at the beam axis [mrad]

The BEAM card: beam shape in the X-Y plane

✱ BEAM

Δp : Flat ▼

Beam: Momentum ▼

p :

Part: ▼

Δp :

$\Delta\phi$: Flat ▼

$\Delta\phi$:

Shape(X): Rectangular ▼

Δx :

Shape(Y): Rectangular ▼

Δy :


Distribution type:

- **Rectangular**: Full beam width in **x/y** direction centred at the beam axis [cm]
- **Gaussian**: FWHM of a Gaussian distribution in **x/y** direction centred at the beam axis [cm]

Default: $\Delta x = 0.0$, $\Delta y = \Delta x$

- **Annular** distribution can be selected in the dropdown menu of **Shape(X)**

- **Rmin** and **Rmax** are the radii of the distribution
- The beam particle position is uniformly sampled on the **x-y** plane between **Rmin** and **Rmax**
- For circular beam use **Rmin = 0.0**



The BEAMPOS card: beam position and direction

BEAMPOS

x:	y:	z:
cosx:	cosy:	Type: POSITIVE ▼

Position:

The beam position is defined with its **x**, **y** and **z** coordinates [cm]

Default: Origin of the coordinate system

Direction:

The beam axis is defined via direction cosines with respect to the x and y axes

The third direction cosine (**cosz**) is automatically calculated by FLUKA

Note that this is not enough for an unequivocal direction definition; the sign of **cosz** has to be provided as well. Select **POSITIVE** or **NEGATIVE** from the *Type* dropdown

Default: Positive z direction

Default beam

- What happens if the **BEAM** and **BEAMPOS** cards are not filled in or are missing?
- FLUKA will use the built-in default (*note: may change in the future*):
 - Protons at 200 GeV/c momentum
 - Pencil beam: No divergence, zero radius
 - Starting from the origin of the coordinate system
 - Directed along the positive z axis
- This is almost never what you want!
- Always complete the relevant information in the **BEAM** and **BEAMPOS** card
- It is good practice to confirm what source you have defined by checking the FLUKA output (see the *Standard output* lecture)

Beam visualisation

- The easiest way to check whether the beam parameters are set correctly is to visualise the beam
- There are two ways to do this:
 - Use the Geoviewer's BEAM object
 - Use standard FLUKA scorings (See the *Scoring* lectures) with **BEAMPART** as particle type
 - USRBIN for particle location and direction
 - USRBDX for energy spectrum (with a closed surface surrounding the source location)

Beam visualisation

- **Example 1:** 1 GeV Gaussian beam | 0.1 GeV/c FWHM momentum distribution | 0.4 rad flat angular distribution | rotated around the y axis by -30°

* **BEAM**
Beam: Energy ▼
E: 1.0
Part: ▼

Δp : Gauss ▼
 Δp (FWHM): 0.1
 $\Delta\phi$: Flat ▼
 $\Delta\phi$: 400.0


Shape(X): Rectangular ▼
 Δx :
Shape(Y): Rectangular ▼
 Δy :

* **BEAMPOS**
x: 0.0
y: 0.0
z: 0.0

cosx: -0.5
cosy: 0.0
Type: POSITIVE ▼


- Geoviewer **BEAM** object:

- Starting point
- Direction
- Angular distribution
- Beam mean energy
- Default scale: 1 GeV(/c) = 1 cm
Can be changed with the scale parameter



Beam visualisation



- FLUKA scoring:



Beam rotation

- **Example 2:** $R = 0.5$ cm cylindrical beam | zero divergence | rotated around y axis by -30°

☀ **BEAM** Beam: Momentum ▾ p: Part: ▾
 Δp : Flat ▾ Δp : $\Delta\phi$: Flat ▾ $\Delta\phi$:
Shape(X): Annular ▾ Rmin: 0.0 Rmax: 0.5
🌐 **BEAMPOS** x: 0.0 y: 0.0 z: 0.0
cosx: -0.5 cosy: 0.0 Type: POSITIVE ▾



- *Remember:* the **BEAM** card sets the X-Y shape of the beam, which is not influenced by the beam direction set in the **BEAMPOS** card... so how can we rotate the beam?

Beam rotation

- Input card: **BEAMAXES**

BEAMAXES

cosBxx:

cosBzx:

cosBxy:

cosBzy:


cosBxz:

cosBzz:

Defines the beam coordinate system (\mathbf{x}' , \mathbf{y}' , \mathbf{z}') with respect to the geometry one (\mathbf{x} , \mathbf{y} , \mathbf{z})


Input fields:

- **cosBxx**: cosine of the angle between \mathbf{x}' and \mathbf{x}
- **cosBxy**: cosine of the angle between \mathbf{x}' and \mathbf{y}
- **cosBxz**: cosine of the angle between \mathbf{x}' and \mathbf{z}
- **cosBzx**: cosine of the angle between \mathbf{z}' and \mathbf{x}
- **cosBzy**: cosine of the angle between \mathbf{z}' and \mathbf{y}
- **cosBzz**: cosine of the angle between \mathbf{z}' and \mathbf{z}




Beam rotation

- **Example 2:** R = 0.5 cm cylindrical beam | zero divergence | rotated around y axis by -30°



WHAT	Beam axis	Geo axis	Angle [°]	Cos(Angle)
cosBxx	x'	x	30	~0.866
cosBxy	x'	y	90	0
cosBxz	x'	z	-60	0.5
cosBzx	z'	x	120	-0.5
cosBzy	z'	y	90	0
cosBzz	z'	z	30	~0.866



BEAMAXES
 cosBxx: 0.86602540378
 cosBxy: 0.0
 cosBxz: 0.5
 cosBzx: -0.5
 cosBzy: 0.0
 cosBzz: 0.86602540378

Volumetric sources

Volumetric sources can be defined with a second **BEAMPOS** card:

- Available types:
 - Spherical shell (**SPHE-VOL**)
 - Cylindrical shell (**CYLI-VOL**)
 - Cartesian shell (**CART-VOL**)
 - Spherical surface (**FLOOD**)
- Volumetric sources are centred around the position defined in the first **BEAMPOS** card
- The location inside the volume is sampled uniformly
- The particle direction and angular distribution set in the first **BEAMPOS** card and the **BEAM** card are still applied
- **Warning:** The spatial distributions specified in the **BEAM** card will be disregarded

Volumetric sources – *Spherical shell*

 **BEAMPOS**

Rin:


Rout:

Type: SPHE-VOL ▼

Specifies a spherical shell shaped source

Input fields:

- **Rin**: Inner radius [cm]
- **Rout**: Outer radius [cm]



Volumetric sources – *Cylindrical shell*

 **BEAMPOS**

Rin:
Hin:

Rout:
Hout:


Type: CYLI-VOL ▼

Specifies a cylindrical shell shaped source around the z axis of the geometry

Input fields:

- **Rin**: Inner radius [cm]
- **Rout**: Outer radius [cm]
- **Hin**: Inner height [cm]
- **Hout**: Outer height [cm]

Note: The reference coordinate system can be changed with the **BEAMAXES** card



Volumetric sources – *Cartesian shell*

 **BEAMPOS**

Xin:

Yin:

Zin:

Xout:

Yout:

Zout:


Type: CART-VOL ▼

Specifies a Cartesian shell shaped source along the axes of the geometry

Input fields:

- **Xin & Xout:** Inner & outer length of the **x**-sides
- **Yin & Yout:** Inner & outer length of the **y**-sides
- **Zin & Zout:** Inner & outer length of the **z**-sides

Note: The reference coordinate system can be changed with the **BEAMAXES** card



Volumetric sources – *Spherical surface source*

 **BEAMPOS**

R:

Type: FLOOD ▼


Specifies a spherical surface source in a way that the fluence inside the sphere is **uniform** and **isotropic**

The value of the generated fluence is: $\frac{1}{\pi R^2} \text{ cm}^{-2}$

Input fields:

- R: Radius of the sphere [cm]

Warning: The particle direction and angular distribution set on the first **BEAMPOS** and the **BEAM** card are disregarded



Multiple beam spots – SPECSOUR

Input card: **SPECSOUR – BEAMSPOT**

Allows to define multiple beam spots

Can be used where the capabilities of the **BEAM**, **BEAMPOS**, and **BEAMAXES** are not sufficient, but more than one beam is required, like for radiotherapy.

 **SPECSOUR** Type: BEAMSPOT ▼ # spots: Sampling: Random ▼

- # spots: Number of defined beam spots, up to 15000
- Sampling: How primaries sampled between the individual beam spots
 - **Random**: The beam spots are sampled randomly, according to their weights
 - **Sequentially weighted**: The beam spots are sampled sequentially each with a number of primaries proportional to its weight
 - **Sequentially equal**: The beam spots are sampled sequentially, all with the same number of primaries, ignoring their weights

Beam spots are defined with **SPOTBEAM**, **SPOTPOS** and **SPOTDIR** cards

Multiple beam spots – SPOTBEAM

```
* SPOTBEAM spot_id    Beam: Momentum ▼          p:          Part: ▼
                        Z: 0          A: 0          Isomer: 0
      Δp: Flat ▼      Δp:          Spot Weight:
      Δφx: Flat ▼    Δφx:          Δφy: Flat ▼      Δφy:
```

Spot definition:

- **spot_id**: ID number of the beam spot. Numbering has to be continuous, starting from 1
Note the unusual location of the input field
- **Spot weight**: Relative intensity of the beam spot

Particle type:

- **Part**: Spot's particle type. If not selected, a heavy ion can be specified with:
 - **Z** (atomic), **A** (mass number), **Isomer**: Specify a heavy ion
- Default.* Particle defined on the **BEAM** card (if no **Part** selected and no heavy ion specified)

Multiple beam spots – SPOTBEAM

```
* SPOTBEAM spot_id  Beam: Momentum ▼          p:          Part: ▼
                        Z: 0                    A: 0          Isomer: 0
      Δp: Flat ▼      Δp:          Spot Weight:
      Δφx: Flat ▼    Δφx:          Δφy: Flat ▼      Δφy:
```

Momentum / energy:


- **Beam:** Defines the **Momentum** [GeV/c] or **Energy** [GeV] or the emitting particle
Default: Momentum / energy defined on the **BEAM** card

Momentum distribution:

- **Δp:** Defines the beam's momentum distribution as:
 - **Flat:** Full width of a rectangular **momentum** distribution centred at beam momentum [GeV/c]
 - **Gaussian:** FWHM of a Gaussian **momentum** distribution [GeV/c]

Default: 0.0 (!)

Multiple beam spots – SPOTBEAM

 SPOTBEAM spot_id	Beam: Momentum ▼	p:	Part: ▼
	Z: 0	A: 0	Isomer: 0
Δp : Flat ▼	Δp :	Spot Weight:	
$\Delta\phi_x$: Flat ▼	$\Delta\phi_x$:	$\Delta\phi_y$: Flat ▼	$\Delta\phi_y$:

Angular distribution:

- $\Delta\Phi_x, \Delta\Phi_y$: Defines the beam's angular distribution in the **x/y** plane, as:
 - **Flat**: Full width of a rectangular angular distribution centred around the beam axis [mrad]
 - **Isotropic**: Isotropic distribution (Input as **Flat** distribution with angle larger than 2π [rad])
 - **Gaussian**: FWHM of a Gaussian angular distribution [mrad]

Default: $\Delta\Phi_x = 0.0$, $\Delta\Phi_y = \Delta\Phi_x$

BEAMSPOT - Visualisation


Input card: **SPECSOUR – BEAMSPOT**

Example:

R = 2 cm water sphere

47.5 MeV, 2.5 mm cylindrical, proton beams

4 spots, in 45° steps, with 2ⁿ weight



BEAM	Beam: Energy ▾	E: 0.0475	Part: PROTON ▾
Δp: Flat ▾	Δφ: Flat ▾		Δφ:
Shape(X): Rectangular ▾	Δx:	Shape(Y): Rectangular ▾	Δy:
SPECSOUR	Type: BEAMSPOT ▾	# spots: 4	Sampling: Random ▾
SPOTBEAM 1	Beam: Momentum ▾	p:	Part: ▾
Z: 0	A: 0		Isomer: 0
Δp: Flat ▾	Spot Weight: 1		
Δφx: Flat ▾	Δφy: Flat ▾		Δφy:
SPOTPOS 1	x:	y:	z: -5
Shape(X): Annular ▾	Rmin:	Rmax: 0.25	
SPOTDIR 1	cosx:	cosy:	cosz:
	cosBxx:	cosBxy:	cosBxz:
SPOTBEAM 2	Beam: Momentum ▾	p:	Part: ▾
Z: 0	A: 0		Isomer: 0
Δp: Flat ▾	Spot Weight: 2		
Δφx: Flat ▾	Δφy: Flat ▾		Δφy:
SPOTPOS 2	x: 5	y:	z: -5
Shape(X): Annular ▾	Rmin:	Rmax: 0.25	
#define angle2	: -45		
SPOTDIR 2	cosx: =sind(angle2)	cosy: 0	cosz: =cosd(angle2)
	cosBxx: =cosd(angle2)	cosBxy: 0	cosBxz: =-sind(angle2)
SPOTBEAM 3	Beam: Momentum ▾	p:	Part: ▾
Z: 0	A: 0		Isomer: 0
Δp: Flat ▾	Spot Weight: 4		
Δφx: Flat ▾	Δφy: Flat ▾		Δφy:
SPOTPOS 3	x: 5	y:	z:
Shape(X): Annular ▾	Rmin:	Rmax: 0.25	
#define angle3	: -90		
SPOTDIR 3	cosx: =sind(angle3)	cosy: 0	cosz: =cosd(angle3)
	cosBxx: =cosd(angle3)	cosBxy: 0	cosBxz: =-sind(angle3)
SPOTBEAM 4	Beam: Momentum ▾	p:	Part: ▾
Z: 0	A: 0		Isomer: 0
Δp: Flat ▾	Spot Weight: 8		
Δφx: Flat ▾	Δφy: Flat ▾		Δφy:
SPOTPOS 4	x: 5	y:	z: 5
Shape(X): Annular ▾	Rmin:	Rmax: 0.25	
#define angle4	: -135		
SPOTDIR 4	cosx: =sind(angle4)	cosy: 0	cosz: =cosd(angle4)
	cosBxx: =cosd(angle4)	cosBxy: 0	cosBxz: =-sind(angle4)

Further possibilities

Sometimes the **BEAM**, **BEAMPOS**, and **BEAMAXES** cards are not enough

- Special sources available in FLUKA
 - Colliding beams
 - Synchrotron radiation
 - Cosmic rays
 - USRBIN source
- Program your own custom sources (Source routine – FLUKA Advanced Course)

2. The FLUKA preprocessor

The FLUKA preprocessor

- A limited, “C”-like preprocessor
- Manipulates the input before execution using directives

- 3 type of directives (starting with: #):
 - Definition:
`#define, #undef`
 - Conditional:
`#if, #elif, #else, #endif`
 - Include:
`#include`

FLUKA preprocessor - *Definition*

Directive: `#define`

- Identifiers without numerical or character value:

④ `#define identifier_name :`

- Used in conjunction with conditional directives (`#if identifier_name ... #endif`)
- *identifier_name* can be up to 40 character long

- Identifiers with numerical or character value:

④ `#define identifier_name : value`

- The *value* can be used in any other input card by referencing `$identifier_name` and can be up to 40 characters long
- Can also be used in conjunction with conditional directives

Directive: `#undef`

④ `#undef identifier_name ▼`

- Deletes a previously defined identifier

FLUKA preprocessor - *Definition*

- Identifiers can be *defined* and *referenced* anywhere in the input file
- Example:


```
# #define Momentum           : 0.1
# #define Particle           : PROTON
* BEAM           Beam: Momentum ▼
    Δp: Flat ▼           Δp:
Shape(X): Rectangular ▼ Δx:
                                p: $Momentum           Part: $Particle ▼
                                Δφ: Flat ▼           Δφ:
                                Shape(Y): Rectangular ▼ Δy:
```

- **Note:** It is possible to redefine an identifier with a second `#define` directive
 - This is **NOT RECOMMENDED**
 - If an identifier is redefined, the new value is only applied to cards below
 - The output and error files will contain warning messages

FLUKA preprocessor - *Conditional*

Directives: `#if`, `#elif`, `#else`, `#endif`

- To include or exclude parts of the input in conjunction with the `#define` directives



- They work similarly to any programming language
 - Limitation:** Cannot compare values, only test if an identifier is defined or not
- Can be nested
 - Limitation:** Maximum of 10 nesting levels can be used

FLUKA preprocessor - *Conditional*

```
# #define NeutronBeam      :  
...  
# #if NeutronBeam ▼  
  * BEAM Beam: Energy ▼ E: 0.1 Part: NEUTRON ▼  
  Δp: Flat ▼ Δp: Δφ: Flat ▼ Δφ:  
  Shape(X): Rectangular ▼ Δx: Shape(Y): Rectangular ▼ Δy:  
# #else  
  * BEAM Beam: Energy ▼ E: 0.05 Part: PHOTON ▼  
  Δp: Flat ▼ Δp: Δφ: Flat ▼ Δφ:  
  Shape(X): Rectangular ▼ Δx: Shape(Y): Rectangular ▼ Δy:  
# #endif  
...  
# #if NeutronBeam ▼  
  * ASSIGNMA Mat: CONCRETE ▼ Reg: SHIELD ▼ to Reg: ▼  
  Mat(Decay): ▼ Step: Field: ▼  
# #else  
  * ASSIGNMA Mat: LEAD ▼ Reg: SHIELD ▼ to Reg: ▼  
  Mat(Decay): ▼ Step: Field: ▼  
# #endif
```


FLUKA preprocessor - *Conditional*

```
# #define NeutronBeam      :  
...  
#if NeutronBeam ▾  
  # #define Energy        : -0.1  
  # #define Particle      : NEUTRON  
  # #define ShieldMa      : CONCRETE  
#else  
  # #define Energy        : -0.05  
  # #define Particle      : PHOTON  
  # #define ShieldMa      : LEAD  
#endif
```

```
...  
* BEAM          Beam: Energy ▾          E: $Energy          Part: $Particle ▾  
  Δp: Flat ▾          Δp:          Δφ: Flat ▾          Δφ:  
  Shape(X): Rectangular ▾          Δx:          Shape(Y): Rectangular ▾          Δy:  
...  
* ASSIGNMA     Mat: $ShieldMa ▾          Reg: SHIELD ▾          to Reg: ▾  
  Mat(Decay): ▾          Step:          Field: ▾
```

FLUKA preprocessor - *Include*

Directive: `#include`

 **#include** <path>/filename.inp ▼

- Includes the specified file to the input
 - Can be nested at multiple levels
-
- The path can be:
 - Relative to the **main input** file
 - Absolute
-
- Use cases:
 - Split large input files into multiple smaller ones
 - Reuse same input section (beam definition, scoring, etc.) in multiple input files



Back-up slides

Multiple beam spots – SPOTPOS

SPOTPOS (optional)

 SPOTPOS <i>spot_id</i>	<i>x:</i>	<i>y:</i>	<i>z:</i>
<i>Shape(X):</i> Rectangular ▼	<i>Δx:</i>	<i>Shape(Y):</i> Rectangular ▼	<i>Δy:</i>

Spot definition:

- **spot_id**: ID number of the beam spot, which this card applies to
Note the unusual location of the input field

Beam spot position:

- **x, y, z**: Position of the beam spot along the **x**, **y**, and **z** axes [cm]

Beam spot shape:

Shape(X), Shape(Y): Defines the spatial distribution of the beam spot, as:

- **Rectangular**: Full beam width in **x/y** direction centred at the beam axis [cm]
- **Gaussian**: FWHM of a Gaussian distribution in **x/y** direction centred at the beam axis [cm]

Default: **Δx** = 0.0, **Δy** = **Δx**

Multiple beam spots – SPOTPOS

SPOTPOS (optional)

 SPOTPOS spot_id	x:	y:	z:
Shape(X): Annular ▼	Rmin:	Rmax:	

Beam spot shape (cont.):

Shape(X): Defines the spatial distribution of the beam spot, as:

- **Annular**: Defines a cylindrical beam shape in the **x-y** plane

Rmin and **Rmax** are the radii of the distribution

For circular beam use **Rmin = 0**

Defaults:

If no values or **SPOTPOS** card provided, then the position and shape is taken from the **BEAM** and **BEAMPOS** cards

Multiple beam spots – SPOTDIR

SPOTDIR (optional)

```
SPOTDIR spot_id      cosx:      cosy:      cosz:
                    cosBxx:    cosBxy:    cosBxz:
```

Spot definition:

- **spot_id**: ID number of the beam spot, which this card applies to
Note the unusual location of the input field

Beam spot direction:

- **cosx, cosy, cosz**: Defines the direction cosines of the beam
Default. Beam direction specified on the **BEAMPOS** card is used

Multiple beam spots – SPOTDIR

SPOTDIR (optional)

```
SPOTDIR spot_id      cosx:      cosy:      cosz:
                    cosBxx:    cosBxy:    cosBxz:
```

Beam spot coordinate system:

- **cosBxx, cosBxy, cosBxz**: Defines the direction cosines of the x axis of the beam coordinate system

Default: Beam coordinate system defined on the **BEAMAXES** card is used

If the x axis of the beam spot coordinate system is specified, the z axis will be the beam spot direction, and the y axis will be automatically computed