



Pulse generator
100Hz NIM PULSE SETUP
TG5011

Step 1:

- Press Stores and then Recall button in order to load the Pulse1 saving.




Step 2 (if Step 1 doesn't work) :




- Select the Pulse and Output buttons.

- Set the Frequency to 100Hz
For entering the value use the keypad.




- Press two times AMPL




- Set Hilvl to 0 V




- Set Lolvl to -1V




- Set the Width to 400ns



- Press the Utility button
- Select Output



- Press Type and select:
- Inverse



- After completing the steps the signal will look like in the picture.

