

BCM2 removal

- Necessary condition: CASTOR table retracted, T2 open.
 - Preferred if collar is removed.
- Preferred date: after 11.3.2013, then as soon as possible.
- Procedure (time estimates per half-wheel, 4 half-wheels in total)
 - Unplug BSC2 fibers and BCM2 DSUB connector (5-10 minutes)
 - Unscrew and remove half-wheel (5 minutes)
- 2 persons needed.
- Tools needed: Alan keys, wrench, tweezers
- Future plans with wheels:
 - Removal of BSC2 tiles (use for tests, or dispose)
 - Removal of BCM detector packages
 - Shipment to DESY for characterization.
 - Wheels should be stored for reinstallation.

