


# **Temperature regulation and measurements on silicon detectors with red & infrared laser beams**


An internship with the SSD Team  
(PH-DT-DD)

- Set up
- Components
- PID controller
- Measuring data
- Further options
  
- TCT measurements
- Setting
- Measuring data
  
- sources

# agenda




# Set up




# Control engineering


Annika Altwein



# Inside the box

Annika Altwein





# Temperature control system 6

Certain set temperature for sensor



It has to be warmed up or cooled down



Controller regulates current flow in peltier element



Peltier element has a stronger/ weaker warming/cooling effect




Warms up/ cools down copper plate



Reach set temperature on sensor

# How does it work



# Peltier element

8



- Temperature control
- Set to the inertia of the system

→ reach set temperature as fast as possible

→ compensates disturbances/ errors

# PID Controller

Three parameters for the controller:

- **P (proportional)**–controller → focusses on present variance
  - Reacts immediately
  - only reaction in case of present error
- **I (integral)**–controller → eliminating steady-state deviation
  - Delayed reaction
  - No impact only in case of constant value without deviation
- **D (derivative)**–controller → prediction due to current change
  - Fast reaction
  - Reacts only to changes, not to deviations in general


# PID Controller

Weighting of the parameters  $\rightarrow$  specific contributions will be summated

$$\underbrace{K_p \cdot e(t)}_{\mathbf{P}} + \underbrace{K_i \cdot \int_{t_1}^t e(\tau) d\tau}_{\mathbf{I}} + \underbrace{K_d \cdot \frac{d}{dt} e(t)}_{\mathbf{D}}$$


# functioning

11



# What it should look like

12



# How does it look

- Find out specific parameters due to curve tracing
- Brute-force-method to find fitting values

→ bigger project than expected, needs more time


# Further options

## Connection between fluence and charge

- measurements with a set of irradiated sensors and laser beams
- comparing the induced current signal caused by charge carriers

# TCT measurements



15



# main idea


16





# red laser from both sides

17



# Radiation with infrared


18

Name	Fluence ( $\frac{P}{cm^2}$ )
4 (in the plot)	Non-irradiated
A2B (in the plot)	$6 \cdot 10^{13}$
B2B (in the plot)	$1 \cdot 10^{14}$
C1A	$5 \cdot 10^{14}$
D1 (in the plot)	$1 \cdot 10^{15}$
E1	$2 \cdot 10^{15}$
O1A (in the plot)	$4 \cdot 10^{16}$

Proton irradiated, PS 24GeV/c  
Float Zone n-in-p


# Radiated sensors

19



## Infra-red from front side (1000V)


20




**Red from back side (1000V)**

**21**

# TCT\_Red\_back\_MCznp\_unirrad





# Infrared from front side

Thank you Sascha  
for the  
organization and  
Christian and the  
SSD group for my  
great internship



[https://www.samson.de/pdf\\_de/1102de.pdf](https://www.samson.de/pdf_de/1102de.pdf)

[http://www.chemgapedia.de/vsengine/vlu/vsc/de/ch/7/tc/regelung/grundlagen/regelung\\_grundlagen.vlu/Page/vsc/de/ch/7/tc/regelung/grundlagen/regler/pid\\_ctrl.vscml.html](http://www.chemgapedia.de/vsengine/vlu/vsc/de/ch/7/tc/regelung/grundlagen/regelung_grundlagen.vlu/Page/vsc/de/ch/7/tc/regelung/grundlagen/regler/pid_ctrl.vscml.html)

<http://www.physik.uni-augsburg.de/~sausemar/FP14/FP14.pdf>

[http://en.wikipedia.org/wiki/PID\\_controller](http://en.wikipedia.org/wiki/PID_controller)

[http://www.hephy.at/fileadmin/user\\_upload/Publikationen/thesis\\_auzinger.pdf](http://www.hephy.at/fileadmin/user_upload/Publikationen/thesis_auzinger.pdf)

Christian Gallrapp

Own measurements

Pictures: own pictures (if not documented differently)

# Sources

25

- Reaction in case of current error
  - reacts immediately
- Grave errors – strong reaction,  
little errors – little reaction

# P-controller

- focusses on preceded errors
  - delayed reaction
- Strong reaction in case of short times of integration, long times of integration lead to less reaction
- Only put out of the running if measured value constant and no error left

# I-Controller

- Focusses only on present change of error, anticipates development
  - fast reaction
- High rate of change leads to strong counteraction
- Responds only to changes, not in case of constant errors (put out of the running)

# D-controller