



Biassing techniques in FLUKA

Concept introduction and basic applications

What is biasing?

- It is the use of “*Variance Reduction Technique*(s)” that...
 - distort distributions and apply weights to particles to correct for the bias
- VRTs aim at reducing variance σ^2 or CPU time t
- Usually, reducing one quantity increases the other
- Usually, more than one VRT is applied at the same time
- Goodness of simulations can be estimated with a Figure of Merit: $FOM=1/(\sigma^2 \cdot t)$
 - the larger the better: less time and smaller uncertainty


Non-biased Monte Carlo simulations

Characteristics

- Samples from
 actual phase-space distributions
- Preserves correlations
- Reproduces fluctuations

Drawbacks

- Converges slowly
- Rare events are... “rare”



Non-biased Monte Carlo simulations



200000 primaries

Characteristics

- Samples uniformly from the phase-space distribution
- Preserves correlations
- Reproduces fluctuations

Drawbacks

- Converges slowly
- Rare events are... “rare”



Biased Monte Carlo simulations


200000 primaries

Characteristics

- Samples from distorted distributions
- Converges “quickly”

Drawbacks

- Cannot reproduce fluctuations and correlations
- Requires active reasoning and experience
- Requires user’s time to be implemented



Biassing techniques in FLUKA

- *Region Importance Biassing* (BIASING)
 - *Mean Free Path Biassing* (LAM-BIAS)
 - Leading Particle Biassing (EMF-BIAS)
 - Multiplicity Tuning (BIASING)
 - Lifetime / Decay-length Biassing (LAM-BIAS)
 - Weight Windows (WW-FACTO, WW-THRES, WW-PROFI)
 - Low energy neutrons non-analogue absorption (LOW-BIAS)
 - Low energy neutrons downscattering (LOW-DOWN)
 - User defined biassing (usbset.f , usimbs.f)
- During this lessons we will only look at these 2 types

Region Importance Biasing

Input card: **BIASING**


Region Importance Biasing

- Input card: **BIASING**
- Simplest form of biasing
- Applied when a particle crosses a region boundary (e.g. from Region1 to Region2)
- Based on *relative importance* of the two adjacent regions:
$$R = i_2/i_1 = \text{“importance of Region2”} / \text{“importance of Region1”}$$
- Combination of two algorithms (see next slides):
 - For $R > 1$: **Surface Splitting**
 - For $R < 1$: **Russian Roulette**
- Allows to compensate for attenuation (due to distance or absorption)
- Can maintain a uniform population
- Can be tuned per particle type
- Multiple **BIASING** cards are allowed

Region Importance Biasing

Surface Splitting


- Moving toward a higher importance region, $R > 1$
- $n = R = i_2/i_1$ particle *replicas* are created
- *Weight* of replicas is $w = 1/R = i_1/i_2 < 1$
- Total weight of all replicas is equal to the weight of the original particles
- FLUKA allowed values: $5^{-1} \leq R \leq 5$



Region Importance Biasing

Russian Roulette

- Moving toward a lower importance region, $R < 1$
- Particle have a survival probability $P_s = R = i_2/i_1$
- *Weight* of surviving particles increases: $w = 1/R = i_1/i_2 > 1$
- Weight of all surviving particles is equal to the weight of all incoming particles
- FLUKA allowed values: $5^{-1} \leq R \leq 5$



I : importance, w : particle weight




Particle survives with probability $I_2/I_1 = 1/3$

Surviving particle weight increased by $I_1/I_2 = 3$

Region Importance Biasing

Example


- 200 MeV electrons on a cylindrical copper target (5 cm radius, 10 cm deep)
- 5000 primaries



Region Importance Biasing

Drawbacks

- Replicas histories differ because of dE/dx fluctuations and multiple scattering, therefore, when crossing into a low density region (e.g. vacuum, air) correlations between replicas can be relevant
- Could require geometry changes
e.g: how to deal with a geometry like this?



Region Importance Biasing

Drawbacks

- Replicas histories differ because of dE/dx fluctuations and multiple scattering, therefore, when crossing into a low density region (e.g. vacuum, air) correlations between replicas can be relevant
- Could require geometry changes
e.g: how to deal with a geometry like this?

<i>R_Sour</i> - region_importance=1	
<i>R_Sh1</i> - region_importance=2	<i>R_strange</i> - region_importance=?
<i>R_Sh2</i> - region_importance=4	
<i>R_Sh3</i> - region_importance=8	
<i>R_Sh4</i> - region_importance=16	
<i>R_of_int</i> - region_importance=32	

Region Importance Biasing

Input card: **BIASING**

- *Type*
 - all particle
 - Hadrons&muons
 - e+,e-, γ
 - low energy neutrons
- *Reg - to Reg - Step*
 - Standard FLUKA region selection
- *Imp*
 - Importance of the selected region(s)

Example explanation:

An *importance=25* is assigned to *all particles* within *region=a2*

 BIASING	Type: All particles ▼	RR:	Imp: 25
Opt: ▼	Reg: a2 ▼	to Reg: a2 ▼	Step:

Region Importance Biasing

Input card: **BIASING**

- *Type*
 - “all regions”
- *Part - to Part - Step*
 - Standard FLUKA particle range selection
- *Mod. M*
 - Modifying factor M
 - Applied to the splitting factor or to the Russian Roulette probability
 - Practical use: inhibit RIB for a specific particle

Example explanation:

A *modifying factor = 0* is assigned to *protons* (*id=1*) in *all regions* i.e. no region importance biasing for protons in any region

BIASING **Type: All regions ▼** **Mod. M: 0**
Opt: ▼ **Part: PROTON ▼** **to Part: PROTON ▼** **Step:**

Mean Free Path Biasing

Input card: **LAM-BIAS**

Mean Free Path Biasing

- Input card: **LAM-BIAS**
- Allows to...
 - ...reduce the inelastic nuclear interaction length of hadrons by a factor λ
 - ...reduce the nuclear interaction length of photons and muons by a factor λ
- Useful for thin or low density target problems
- Useful to enhance photonuclear reactions (see **PHOTONUC** card)
- Weight is adjusted
- It can be applied to specific materials and/or specific particles
- Multiple **LAM-BIAS** cards are allowed

Mean Free Path Biasing

Input card: **LAM-BIAS**

- *Type*

- <empty> *Interaction length biasing*
- DCDRBIAS Decay direction biasing (advanced topics)
- DCY-DIRE Decay direction biasing (advanced topics)
- DECALL Particle generation selection for **LAM-BIAS** (advanced topics)
- DECPRI Particle generation selection for **LAM-BIAS** (advanced topics)
- GDECAY Lifetime / decay-length biasing (advanced topics)
- INEALL Particle generation selection for **LAM-BIAS** (advanced topics)
- INEPRI Particle generation selection for **LAM-BIAS** (advanced topics)
- N1HSCBS Under development

Mean Free Path Biasing

Input card: **LAM-BIAS**

- *Type*
 - <empty>
- *x mean life*
 - Doesn't apply
- *x λ inelastic*
 - Interaction length correction factor
- *Mat*
 - Material where the correction factor applies
- *Part - to Part - Step*
 - Standard FLUKA particle selection

Example explanation:

Proton interaction length in *beryllium* is multiplied by a factor *correction factor=0.02* (reduced by a factor 50)




LAM-BIAS **Type:** ▼ **x mean life:** **x λ inelastic: 0.02**
Mat: BERYLLIU ▼ **Part: PROTON** ▼ **to Part:** ▼ **Step:**

Mean Free Path Biasing

Input card: **LAM-BIAS**

- Primaries: 100 MeV protons
- Target: 0.1 mm thick beryllium disk
- Spectrum of outgoing protons
- Black: no biasing applied
- Red: MFP biasing applied



LAM-BIAS Type: ▼ × mean life: × λ inelastic: 0.02
Mat: BERYLLIU ▼ Part: PROTON ▼ to Part: ▼ Step:

Summary of the input cards seen

Summary of the input cards seen

- **BIASING**

- Region Importance biasing (Surface Splitting and Russian Roulette)

- **LAM-BIAS**

- Mean free path biasing (interaction length)
- Lifetime / Decay-length biasing (not shown in these slides)

