EUROPEAN
PLASMA RESEARCH
ACCELERATOR WITH
EXCELLENCE IN
APPLICATIONS



Stable beam-driven wakefield in structured plasmas

Alexander Pukhov, Lars Reichwein, John Farmer







Contents



- High transformer ratio acceleration:
 - Sequences of short driver bunches
 - Triangular drivers
- Structured plasma channels

(rather crazy)

- External structures (SWFA or DWA) and plasma guiding (crazy)
- Efficient THz coupling

(low hanging fruit)



Transformer ratio



- Let us assume, we have a driver with current profile $j(\xi)=j_0f(\xi,\mu,\sigma), \qquad \xi=\omega_p(x-ct)$ where μ is the bunch centre position, σ is the bunch length
- We define the (unloaded) transformer ratio as

$$R_W = \frac{\max(E_{acc}(\xi))}{\max(E_W(\xi))}$$

where $E_W(\xi) = E(\xi)f(\xi,\mu,\sigma)$ is a weighted field acting on the driver



Transformer ratio



• The wake field is $E(\xi) = \int_{-\infty}^{\xi} j(\xi') \cos(\xi - \xi') d\xi'$ (driven oscillator)

For a short driver, the transformer ratio is limited

$$R_W \leq 2$$

R. D. Ruth, A. W. Chao, P. L. Morton, and P. B. Wilson, Part. Accel. 17, 171 (1985)


• This implies many acceleration stages, when charged particle drivers are used Or use highly energetic hadron drivers to accelerate leptons (see AWAKE)



Transformer ratio square bunches



- Increase the transformer ratio using pulse trains
- Works pretty well for square bunches:



Choosing a sequence of *N* bunches with

$$j_n = (2n - 1)j_1$$

One achieves

$$R = 2N$$


Farmer et al. Phys Plas 22, 123113 (2015)



Transformer ratio Gaussian bunches



• Gaussian bunches do not scale. Transformer ratio is limited




Farmer et al. Phys Plas 22, 123113 (2015)



Long triangular drivers



• Wake field:
$$E(\xi) = \int_0^{\xi} j_0 \frac{\xi'}{\sigma_z} \cos(\xi - \xi') d\xi' = j_0 \begin{cases} \frac{1}{\sigma_z} (1 - \cos \xi), & \xi < \sigma_z \\ \sin(\xi - \sigma_z), & \xi > \sigma_z \end{cases}$$



Triangular drivers with length $\sigma_z\gg 1/k_p$

can excite wakes with large transformer ratios

$$R = k_p \sigma_z \gg 1$$



Stability of long triangular drivers?




- Uniform plasma: self-modulation and hosing instabilities
- Hollow plasma channels: asymmetric modes and BBU
- Structures: maximum gradient is limited by external focusing because of Beam Break Up instabilities
- Possible alternative: *structured hollow channels*




Wedge plasma channel



Round hollow channel




Wedge plasma





Wedge plasma channel









Wake in wedge plasma channel







Triangular
10 GeV driver


Transformer ratio


 $R \approx 7$



Focusing in wedge plasma channel








 $\chi/\lambda_{\rm p}$


Focusing to the cusps in the both transverse dimensions



Focusing in wedge plasma channel










Acceleration in wedge plasma channel




14






Acceleration in wedge plasma channel








Driver has lost about half of its energy




Electron and positron spectra





Electrons



Positrons




Wedge plasma channel



Central question: how to create such a plasma channel?

Laser ionization of neutral gas?





Marry SWFA/DWA with Plasma



Solid state structures are easier to handle

- Acceleration and focusing in plasma are intrinsically coupled
- We can decouple focusing from acceleration:
 - use structures to generate the accelerating fields
 - use plasma to guide and focus the bunches
 (limitation: only negative charges can be accelerated)

J. Rosenzweig on Wednesday)

K. Bane and G. Stupakov, NIMA 690, 106 (2012)



SWFA/DWA and Plasma




Various structures can be used for acceleration

Dielectric structures

Dielectric Netal cladding Pulse length c Beam direction

Corrugated metallic pipe



J. Rosenzweig on Wednesday)


K. Bane and G. Stupakov, NIMA 690, 106 (2012)



SWFA and **BBU**



The main limit for SWFA: Beam Break Up (BBU)



Tail of the bunch is attracted to the wall


Fig. by Alexandr Moiseevich Altmark



BBU instability in a hollow channel



The main limit for SWFA: Beam Break Up (BBU)






SWFA and BBU



22

Strong focusing (and chirp) is required to stabilize the BBU



1.5 T quadrupoles can provide (may be) up to 100 MV/m stable accelerating fields

S. S. Baturin and A. Zholents Stability condition for the drive bunch in a collinear wakefield accelerator Phys. Rev. Accel. Beams **21**, 031301 (2018)



SWFA and Plasma



Let us decouple acceleration and focusing We use the structure to support accelerating wake while plasma provides focusing only!

Plasma can provide focusing strength as high as

$$\frac{B}{r}$$
 [T/mm] $\approx 6 \cdot 10^4 \sqrt{\frac{n_e [\text{cm}^{-3}]}{10^{15}}}$


when all electrons are swept away from the plasma channel



SWFA and Plasma




Narrow plasma column: Complete stabilization, $R \approx 5$





SWFA and Plasma





bunches

plasma electrons

The leading bunch scatters away electrons off the narrow plasma column


The trailing bunches stay stable and tightly focused by the ion column


How to create the plasma column?



THz: Narrow band CCR (J. Rosenzweig)










THz radiation inside corrugated pipe





Very similar to dielectric, but there is a point



THz radiation inside the closed structure



The corrugated metallic pipe acts *as a dielectric* for *longitudinal* polarization

It works as a metallic rod for radial polarization

Thus, it supports Sommerfeld modes in free space


Removing the metal mantle we let the THz radiation from inside to couple to the Sommerfeld modes outside



EUPRA Coupling THz radiation to Sommerfeld mode



Sommerfeld mode is released at the end of the structure



Energy conversion into THz up to 100%



Conclusions



- High transformer ratio acceleration: the path to reduce the number of stages
- Structured plasma channels: stabilization of BBU

(rather crazy)

 Plasma in external structures (SWFA or DWA) can stabilize the driver and the witness

(crazy)

 Efficient THz coupling in open corrugated metallic structures

(low hanging fruit)