


# Problems with unknown capacitance for irradiated sensors




# Clarification

- When talking about issues for irradiated sensors, I **DO NOT** mean
  - That I think that radiation damage varies the capacitance of the injection capacitor
  - That it hinders basic operation of the sensors
- I **DO** mean
  - That evaluating the effect of radiation damage on the sensor is severely hindered

# Problems with varying capacitance with the MP4

- Allows for a known voltage (charge if capacitance is known) → ToT response curve
- Calibration of charge capacitor typically done using radioactive source
  - Preferably Fe-55 or Am-241 due to distinct peaks



C\_inj is a Varactor not metal traces  
laying over one another (also true for C\_fb?)



# Measuring capacitance



- Fe-55 is not possible as  $Q_{\text{Fe55}} < Q_{\text{threshold}}$
- Am-241 is not possible as we cannot discern any peaks (noise?)
  - A different sensor (200 micron hybrid) had no such issues

Am-241 spectrum  
Reference hybrid




# Measuring capacitance

- Alternative is using Sr90 using the MPV basing it on MIP deposition
- The ratio of seen charge to expected charge gives the “true” capacitance
- This works only because we make the assumption that we see all charge



## We make the assumption charge is 20ke-

- The whole basis on which we determine the capacitor is the assumption that we collect 100% of the expected charge
- With this assumption we can see the capacitance in the same board, pixel-pixel varies by up to a factor 3.5
- This assumption does **NOT** work for irradiated sensors
- At some level we will see charge loss due to
  - trapping
  - insufficient depletion



From Andres presentation last week

# Conclusion

- When operating with irradiated chips we have one equation with two unknowns
  - The injection capacitance
  - The amount of collected charge
    - Not possible to determine the true performance
- One possibility is to see if other monochromatic sources of charge beyond Fe-55 instead of Am-241 work (x-ray fluorescence for example, but that requires a lot of setup)
- Another possibility is to irradiate already bonded chips on boards, however that means a lot of irradiated material meaning the system is very “hot”