

Integrating Pixel Array Detectors

Sol Gruner
Dept. of Physics & CHESS
Cornell University

Detector development group

Mark Tate

Alper Ercan

Dan Schuette

Darol Chamberlain

Lucas Koerner

Hugh Phillip

Marianne Pouchet

Former members


Sandor Barna

Bob Wixted

Eric Eikenberry

Guisepe Rossi

Matt Renzi



Basic Pixel Array Detector (PAD)

Diode Detection Layer

- Fully depleted, high resistivity
- Direct x-ray conversion
- Silicon, GaAs, CdTe, etc.


Connecting Bumps

- Solder or indium
- 1 per pixel

CMOS Layer

- Signal processing
- Signal storage & output

Gives enormous flexibility!



Analog Integrating vs. Photon Counting

Why Analog-Integrating?

Some Common Sense Rules

Rule #1: There is no universal detector. At best, a given detector is well-suited for a given application.

- **Community needs are met by a spectrum of detectors optimized for different applications.**
- **Analog PADs meet specific needs. Examples will follow.**

Why Analog-Integrating?

Some Common Sense Rules

The goal of most x-ray expts is to accurately measure an x-ray intensity.

Rule #2: The accuracy of a given measurement is not necessarily better or worse just because a photon-counting or an analog-integrating detector is used.

Accuracy depends on many real-world details of both the experiment and the detector, including:

- **Calibrations**
- **Stability**
- **Photon loss due to, e.g., pixel signal-sharing, charge recombination, count-rate limitations, and x-ray absorption by inert structures**
- **Systematic effects, e.g., cross-talk, pickup noise**

Analog-integrators have successfully demonstrated excellent performance to appropriate accuracy in certain experiments.

Why Analog-Integrating?

Some Common Sense Rules

Rule #3: Any detector is only as good as its calibration. In practice area detectors rarely achieve accuracies of 1%, and never better than a few tenths percent.

This is especially true for:

- **Signals whose width is smaller than a pixel**
- **Very high local count-rates**

For certain applications, analog-integrators have been very successfully calibrated.

Why Analog-Integrating?

Some Common Sense Rules

Rule #4: No matter how good a detector is in principle, nasty surprises always emerge during stringent performance tests.

Analog-integrators have been around long enough that many of the nasty surprises are understood.

Analog-Integrating PADs are especially useful for...

- **Very high local count-rates. Examples:**
 - ✓ **Time-resolved radiography (e.g., $>10^{10}$ x-ray/pix/sec)**
 - ✓ **Many XFEL & ERL applications (e.g., x-rays in femtoseconds)**
 - ✓ **Very low contrast imaging against high local backgrounds**

Analog-Integrating PADs are especially useful for...

- **Very high local count-rates. Examples:**
 - ✓ Time-resolved radiography (e.g., $>10^{10}$ x-ray/pix/sec)
 - ✓ Many XFEL & ERL applications (e.g., x-rays in femtoseconds)
 - ✓ Very low contrast imaging against high local backgrounds
- **Accurate measurements of small-sized signals. Examples:**
 - ✓ **Microcrystallography from low mosaic spread crystals.**
 - ✓ **Micro-radiography and tomography**
 - ✓ **Accurate difference imaging of spatially fine features.**

Analog-Integrating PADs are especially useful for...

- **Very high local count-rates. Examples:**
 - ✓ Time-resolved radiography (e.g., $>10^{10}$ x-ray/pix/sec)
 - ✓ Many XFEL & ERL applications (e.g., x-rays in femtoseconds)
 - ✓ Very low contrast imaging against high local backgrounds
- **Accurate measurements of small-sized signals. Examples:**
 - ✓ Microcrystallography from low mosaic spread crystals.
 - ✓ Micro-radiography and tomography
 - ✓ Accurate difference imaging for images with fine features.
- **Problems involving complex analog signal processing. Example:**
 - ✓ **In-pixel time-correlation of images (e.g., high count-rate speckle experiments).**

Specific Example: High Speed Imaging

Design Requirements

Rapid Framing Imager

In pix storage for several frames

Selectable integration time (μs to seconds)

Dead time $<$ few μs


Well-depth $> 10^4$ x-rays/pixel/frame (for 1% statistics)

Count rate $> 10^{10}$ x-rays/pixel/s  Analog integration needed

Pixel size $\leq 150 \mu\text{m}$ square

Standard CMOS fabrication service

Cornell Analog PAD




Cornell 100x92 Analog PAD

1.2 mm HP CMOS process (MOSIS)
(Linearized Capacitors)
15 x 13.8 mm² active area; 100x92 pixels
150 mm square pixel
300 mm thick, high resistivity Si diode wafer (SINTEF)
120 mm solder bump bond (GEC-Marconi)

100x92 PAD developers include:

Sandor Barna
Eric Eikenberry
Alper Ercan
Sol Gruner
Matt Renzi
Giuseppe Rossi
Mark Tate
Bob Wixted



G. Rossi, *et al*, J Synchrotron Rad. (1999). **6**, 1095-1105.

100 x 92 Prototype Tests

Test results with 8.9 keV x-rays

• Full well capacity (x-rays)	17000
• Non-linearity (% full well)	< 0.5 %
• RMS read noise : (x-rays/pixel)	2.0 – 2.8
• Dark current (-20 C) (x-ray/pixel/s)	1.6 – 7.7
• Dark current (-20 C) (fA/pixel)	6 – 40
• Storage capacitor leakage	0.07% / s
• PSF (@75 μ m)	< 1%
• X-rays stopped in diode	97 %
• Minimum integration period (μ s)	0.15
• Minimum deadtime between frames (μ s)	0.6
• Rad damage threshold (kRad, CMOS oxide)	30
• Tolerable radiation dose (kRad)	>300

High speed radiography: Supersonic spray from diesel fuel injector

X-ray beam

- CHESS Beamline D-1
- 6 keV (1% bandpass)
- 2.5 mm x 13.5 mm (step sample to tile large area)
- $10^8 - 10^9$ x-rays/pix/s
- 5.13 μ s integration (2x ring period)


Diesel Fuel Injection System

- Cerium added for x-ray contrast
- 1350 PSI gas driven
- 1.1 ms pulse
- 1 ATM SF₆ in chamber



Collaboration: Jin Wang (APS) & S.M. Gruner (Cornell)

See: McPhee, Tate, Powell, Yue, Renzi, Ercan, Narayanan, Fontes, Walther, Schaller, Gruner & Wang

Science **295** (2002) 1261-1263.




High speed radiography: Supersonic spray from diesel fuel injector



Diesel fuel injector spray


- 1.3 ms time sequence (composite of 34 sample positions)
- 5.13 μs exposure time (2.56 μs between frames)
- 168 frames in time (21 groups of 8 frames) Average 20x for S/N
- Sequence comprised of 5×10^4 images



A. MacPhee, *et al*, Science (2002). **295**, 1261-1263.

Diesel fuel injector spray

- 1.3 ms time sequence (composite of 34 sample positions)
- 5.13 μs exposure time (2.56 μs between frames)
- 168 frames in time (21 groups of 8 frames) Average 20x for S/N
- Sequence comprised of 5×10^4 images



A. MacPhee, *et al*, Science (2002). **295**, 1261-1263.

Gasoline fuel injector spray

X-ray beam


- CHESS Beamline D-1
- 6 keV (1% bandpass)
- 2.5 mm x 13.5 mm
- (step sample to tile large area)
- 10^9 x-rays/pix/s
- 5.13 μ s integration (2x ring period)

Fuel injection system


- Cerium added for x-ray contrast
- 1000 PSI gas driven
- 1 ms pulse
- 1 ATM Nitrogen

Collaboration: Jin Wang (APS) & S.M. Gruner (Cornell)

See: Cai, Powell, Yue, Narayanan, Wang, Tate, Renzi, Ercan, Fontes & Gruner
Appl. Phys. Lett. 83 (2003) 1671.




Gasoline fuel injector spray



- 1.8 ms time sequence (composite). 10^5 images
- 5.13 μs exposure time. (15.4 μs between frames)
- 88 frames (11 groups of 8 frames), Avg. 20x for noise.
- 1000 x-rays/pixel/ μs
- Data taken with 4 projections.


Spray is very nonuniform




Experimental Setup is Nontrivial

**Ideally, want to use a video-like mode to set-up experiment,
then switch to quantitative mode for data collection.**

Faster Duty-Cycle: Push-Pull Configuration with Selectable Gain




16x16 Push-Pull laser tests



Moving laser spot

PAD design: Matt Renzi, Alper Ercan

Tests: Alper Ercan



**Laser shining
through chalk dust
water.**

120 frames/sec

Mixed-Mode Motivation

- **Calibration issues limit accuracy to few tenths percent, e.g., 1 part in 1,000 exceeds state-of-art.**
- **Range of numbers in an image (e.g., SAXS) may span many orders of magnitude.**

Suggests that users really want to record images that span many orders of magnitude of intensity across the image, but only need few tenths % accuracy at any location.

Mixed Mode Pixel

Crystallography detector:

Goals:

- Increase dynamic range (10^7 x-rays)
- Keep high count rates ($>10^8$ Hz)
- Fast framing (< 1 ms dead time)
- 2k x 2k pixels, 150 μ m pixel size

Methods:

- Integrating pixel w/ digital overflow counter / charge reset
- Analog remainder read at end of frame
- Fabricated in 0.25 μ m TSMC 3.3 V, metal on metal capacitors

Collaboration with ADSC. See


S.G. Angello, et al, *IEEE 2004 Nuc. Sci. Symposium*, Rome, (Oct. 16-22, 2004).

Integrating PAD for LCLS

Single Particle Imaging

Imaging requirements

- Large solid angle coverage
 - <230 fs pulses. Perhaps 2fs.
 - > 120 Hz framing
 - 10^{12} x-rays/pulse
 - 0 – 1000 x-rays / pixel
- Distinguish between
0 and 1 x-ray



Pixel detector 1: Wide angle

S/N per x-ray $\gg 1$

Dynamic range $\sim 10^3$

> 512 x 512 pixels


Pixel detector 2: Small angle

S/N per x-ray ~ 1

Dynamic range $\sim 10^3 - 10^4$

> 512 x 512 pixels

Integrating PAD for LCLS Pixel Schematic



Increase S/N for low dose
Smaller full well
CDS circuitry

1 ADC per pixel

END