Machine Protection


CERN CAS, November 2013

Jörg Wenninger

CERN Beams Department

Operation group – LHC section





Introduction

Stored energy & interaction with matter

Machine protection design

Example from LHC

The unexpected

Summary

Safety at accelerators - definitions




Accelerators, as all other technical systems, must respect some general principles with respect to safety:

- □ Protect the people (legal requirements).
- Protect the environment (legal requirements).
- Protect the equipment (asset management).
 - Without beam : superconducting magnets, high power equipment, power cables, normal conducting magnets, RF systems, etc.
 - With beam: damage caused by beams.
- □ Those 3 aspects may be coupled in some circumstances!

This presentation on "Machine Protection" is focused on equipment protection from damage caused by <u>beams</u>.

CERN

Trends in modern accelerators



All major accelerator projects are pushed to new records.

- □ Higher beam energy and intensity:
 - Hadron colliders LHC.
 - Linear e+e- colliders.
 - CERN Future Circular Colliders study.

Frequent mixing of superconducting magnets/RF and high power beams

- □ Higher power and brightness:
 - Neutron spallation sources.
 - Neutrino physics.
 - Synchrotron light sources (synchrotron light power).
 - >> the energy (density) stored in the beams increases!

In many modern projects machine protection aspects have a large impact on (or may even dominate) design and operation

Modern accelerators



- □ High power accelerators from some 10 kW to above 1 MW.
 - Neutron spallation sources (SNS, ISIS).
 - > High power/high duty cycle machines (PSI cyclotron, JPARC).
- □ High energy hadron colliders and synchrotrons.
 - LHC and its upgrades.
 - Synchrotrons for fixed target experiments (SPS).
- □ e+e- colliders.
 - > B-factories (KEKB, super-KEKB).
- Synchrotron light sources.
 - > High power photon beams.
- □ Linear colliders/ Free Electron Lasers (FEL).
 - > SLAC linac, ILC, CLIC, FLASH, XFEL.
- Energy recovery linacs.
- Medical accelerators.
 - > The patients!

CERN

Risks and protection




Protection is required since there is some risk.

Risk = probability of an accident

x consequences (in Euro, downtime, radiation doses).

- □ Probability of an uncontrolled beam loss:
 - What are the failures that lead to beam loss into equipment?
 - What is the probability for the failure modes?
- □ Consequences:
 - Damage to equipment.
 - Downtime of the accelerator for repair.
 - Activation of material, dose to personnel.
 - >> The higher the risk, the more protection becomes important!





Introduction

Stored energy & interaction with matter

Machine protection design


Example from LHC

The unexpected

Summary

CERN

Relevant parameters for MPS



- Momentum of the particle
- □ Particle type

Activation is mainly an issue for hadron accelerators.

- □ Energy stored in the beam
 - 1 MJ can heat and melt 1.5 kg of copper.
 - 1 MJ = energy stored in 0.25 kg of TNT.

Key factor:

how easily and how fast

the energy is released!!

- Beam power
- Beam size
- □ Time structure of beam

The kinetic energy of a 200 m

One LHC beam = 360 MJ = ?

90 kg of TNT



8 litres of gasoline

15 kg of chocolate




long train at 155 km/hour






Stored energy chart






Beam loss in materials



- Lost particles induced particle cascades in materials they traverse.
 - The peak energy deposition can be deep in the material at the maximum of the hadron / electromagnetic shower.
 - Particle showers from hadrons with energies of 100's of GeV to some TeV have a penetration depth of some meters.



- □ The energy deposition leads to a temperature increase, and for very fast losses to shock waves and to plastic deformation.
 - Material can melt, vaporize, deform or lose its mechanical properties.
 - o Limited risk for some 10 kJ, large risk for some MJ.
 - Equipment becomes activated due to beam losses.
 - Superconducting magnets can quench (become normal-conducting).

7 Nov 2013




From uncontrolled damage tests...




A real case from the 2008 SPS run!

- Impact on the vacuum chamber of a 400 GeV beam of 3x10¹³ protons (**2 MJ**).
- Event is due to an insufficient coverage of the SPS MPS (known!).
- pressure, downtime ~ 3 days.



...to controlled damage tests



- □ In the past decade a lot of effort was invested to better understand the interaction of high energy / high density beams with matter.
- Experiments:
 - Ad-hoc experiments for the LHC,
 - o Construction of a dedicated test facility at CERN (HiRadMat @ SPS).
- Modeling and comparison with tests.
 - Many matter phases (solid, liquid, plasma), 'hydro-codes'.
- Some outcomes:
 - ✓ Validation of LHC carbon collimator robustness,
 - ✓ Validation of damage thresholds for LHC injection energy,
 - √ Validation of simulation codes,
 - ✓ Search for more robust material.




SPS experiment : damage at 450 GeV



Controlled SPS experiment / protons.

- Energy 450 GeV,
- Beam area $\sigma_x \times \sigma_v = 1.1 \times 0.6 \text{ mm}^2$,
- □ Damage limit for copper at 2×10¹² p.
- No damage to stainless steel.




36 (J s	hot	Intens	sity / p+		
	444	A	1.2	×10 ¹²		
		<u> </u>	2.4×10 ¹²			
	C		4.8×10 ¹²			
10		D		7.2×10 ¹²		
Α	В	D	С			
		0	0	6 cm		

- ➤ Damage limit is ~200 kJ, < 0.1 % of a nominal LHC beam.
- ► Impact D: ≈ 1/3 of nominal LHC injection.


HiRadMat tests – new materials



Courtesy A. Bertarelli (EN)




Inermet 180, 72 bunches



Molybdenum, 72 & 144 bunches



Molybdenum-Copper-Diamond 144 bunches




Glidcop, 72 bunches (2 x)



Molybdenum-Graphite (3 grades) 144 bunches











HRMT14: high intensity tests



Inermet: comparison between simulation and experiment






Case	Bunches	p/bunch	Total Intensity	Beam Sigma	Specimen Slot	Velocity
Simulation	60	1.5e11	9.0e12 p	2.5 mm	9	316 m/s
Experiment	72	1.26e11	9.0e12 p	1.9 mm	8 (partly 9)	~275 m/s

Release of 600 MJ at LHC




The 2008 LHC accident happened during test runs without beam.

A magnet interconnect was defect and the circuit opened. An electrical arc provoked a He pressure wave damaging ~600 m of LHC, polluting the beam vacuum over more than 2 km.







Introduction

Stored energy & interaction with matter

Machine protection design

Example from LHC

The unexpected

Summary

CERN

Modern Machine Protection System: P³



Protect the machine

Highest priority is to avoid damage of the accelerator.

Protect the beam

- Complex protection systems reduce the availability of the accelerator, the number of "false" interlocks stopping operation must be minimized.
- Trade-off between protection and operation.

Provide the evidence

- Clear (<u>post-mortem</u>) diagnostics must be provided when:
 - the protection systems stop operation,
 - something goes wrong (failure, damage, but also 'near miss').

Beam loss



In accelerators, particles are lost due to a variety of reasons: beam gas interaction, losses from collisions, losses of the beam halo, ...

- Some (continuous) beam losses are inherent to the operation of accelerators.
 - Taken into account during the design of the accelerator.
 - Max. loss rates may be given by the design:
 - Prevent magnet quenches (LHC).
 - > Allow maintenance (residual contact radiation).
- Accidental beam losses are due to a multitude of failures mechanisms.

Analysis and structure required!

Failure classification



□ Failure type:

- Hardware failure (power converter trip, magnet quench, AC distribution failure, object in vacuum chamber, vacuum leak, RF trip,).
- Controls failure (wrong data, wrong magnet current function, trigger problem, timing system, feedback failure, ..).
- Operational failure (chromaticity / tune / orbit errors, ...).
- Beam instability (high beam / bunch current).

□ Failure parameters:

- Damage potential.
- Probability for the failure.
- Time constant for beam loss.




Mixture defines the risk and the criticality for MP

■ Machine state (when failure occurs):

- Linac, beam transfer, injection and extraction (single pass).
- Stored beam.

MPS design strategy



- □ Avoid a failure by design if you can.
- Detect a failure at the hardware (equipment) level and stop operation
 first protection layer.
- □ Detect the consequences of the failure on beam parameters (orbit, tune, losses etc) and stop operation second protection layer.
- Stop beam operation.
 - Inhibit injection,
 - Send beam to a dump,
 - Stop the beam by collimators / absorbers.
- □ Elements of protection:
 - ✓ Equipment and beam monitoring,
 - ✓ Collimators and absorbers,
 - ✓ Beam dumps,
 - ✓ Interlock system linking different systems.

7 Nov 2013



Passive and active protection



Passive protection

- Collimators.
- o Masks.
- o Absorbers.
- o Dumps.

Obstacles to absorb the energy

Active protection

- Equipment surveillance.
- o Beam observation.
- Extraction (dump) kickers.

Detection of a failure directly on the equipment or by its effects on the beam.

Modern MP systems usually require both passive and active protection to cover all failure cases.

Failure time scales – circular machines



Time scale

ns -µs

- □ Single turn (single-passage) beam loss
 - Failures of kicker magnets (injection, extraction) kicker magnets).
 - Transfer failures between two accelerators or from an accelerator to a target station.

Passive protection

High reliability

- □ Very fast beam loss (µs ms)
 - Multi turn beam losses in rings.
 - Large variety of possible failures, mostly in the magnet powering system, with a typical time constant of some 10 turns to many seconds

Fast beam loss

Slow beam loss

us-ms


10 ms - s

many s

Active Protection

Passive protection





Introduction


Stored energy & interaction with matter

Machine protection design

Example from LHC


The unexpected

Summary





CERNY


Beam loss monitoring



- Ionization chambers are used to detect beam losses:
 - \circ Very fast reaction time $\sim \frac{1}{2}$ turn (40 μs)
 - Very large dynamic range (> 10⁶)
- □ ~3600 chambers (BLMS) are distributed over the LHC to detect beam losses and trigger a beam abort!
- □ BLMs are good for almost all failures as long as they last ~ a few turns (few 0.1 ms) or more!









CERNY

Beam collimation (cleaning)




- □ The LHC requires a complex multi-stage collimation system to operate at high intensity.
 - Previous hadron machines used collimators only for experimental background conditions.







Collimation system



Experiment

- □ To be able to absorb the energy of the protons, the collimators are staged – primary, secondary, tertiary – multi-stage system.
- □ The system worked perfectly also thanks to excellent beam stabilization and machine reproducibility – only one setup / year.
 - ~99.99% of the protons that were lost from the beam were intercepted.
 - No magnet was quenched in operation at 3.5/4 TeV.






Continuous beam losses at LHC





- □ The BLM signals near the experiments are almost as high at the collimators (steady losses) due to the luminosity.
 - At the experiments the BLM record collision debris in fact the physics at small angles not covered by the experiments!!



7 Nov 2013

LHC beam dumping system





LHC dump line




The LHC dump block





The end – for the beam!






☐ The dump is the only LHC element capable of absorbing the nominal beam.

Beam swept over dump surface to lower the power density.

□ A beam screen installed in front of the dump provides monitoring of the dump execution.

The shape of the beam impact is checked against prediction at each dump!



Failure analysis process – step (1)



Let us pick an example for the LHC

- □ Step 1: Figure out what can go wrong...
 - Requires good understanding of accelerator physics: how does a given element affect the beam?
 - Requires good understanding of the hardware: time scales, failure modes?
 - Requires a complete overview of all machine equipment that affect the beam.
 - The analysis must be done systematically for every system, from bottom up – including the software/controls.




Failure analysis process – step (2)



□ Step 2: Identify a critical element – the D1's.





CERN


Failure analysis process – step (3)





- Step 3: Simulate the failure.
 - 12 magnets are powered in series.
 - ∘ Large betatron function when squeezed $(\beta > 2000 \text{ m}) \rightarrow \text{large orbit changes}.$
 - Short time constant $\tau = 2.5$ seconds (B is the magnetic field):

$$B(t) = B_0 e^{-t/\tau}$$

Simulated orbit change along the LHC ring a few **milliseconds** after failure.











It does not fit!

CERN

Failure analysis process – step (4)




- The simulations indicate absence of redundancy (we only have beam loss monitors) and very short reaction times for BLMs → we want an extra-layer of protection at the equipment level.
- This analysis triggered the development of so-called FMCMs (Fast Magnet Current change Monitor) that provide protection against fast magnet current changes after powering failures CERN DESY/Hamburg collaboration.



Failure analysis process – step (5)



- □ Step 5: Test failure of PC and FMCM reaction.
 - Switch off D1 PC simulated failure.






Failure analysis process – step (6)




- Step 6: Real test with beam no FMCM
 - Low intensity ('safe') test beam.
 - Switch off D1 PC simulated failure.
 - Beams dumped by the LHC BLMs when beams hit the collimators.






Failure analysis process – step (7)



- □ Step 7: Real test with beam with FMCM
 - Low intensity ('safe') test beam.
 - Switch off D1 PC simulated failure.
 - Beam dumped by FMCM.







Wenninger


Machine Protection

CERN CAS

Nov 2013

Timescales @ LHC






Nov 2013



The beam's gone immediately isn't it?




- Unfortunately even the best failure detection takes some time, the signal must be propagated to the dumping system, the dumping system must synchronize to the beam.
 - Unavoidable delay to fire the dump!




At the LHC the delay can be up to ~ 3 turns – $\sim 300 \mu s$.

7 Nov 2013


Learning curve



It took more than a year of commissioning and tuning (e.g. BLM) thresholds) to reach the maximum intensity at 3.5/4 TeV







Introduction

Stored energy & interaction with matter

Machine protection design

Example from LHC

The unexpected


Summary


Surprising 'Unidentified Falling Objects'



- Very fast and localized beam losses were observed as soon as the LHC intensity was increased in 2010.
- The beam losses were traced to dust particles falling into the beam 'UFO'.
- If the losses are too high, the beams are dumped to avoid a magnet quench.
 - -~20 beams dumped / year due to UFOs.
 - We observe conditioning of the UFOrate from ~10/hour to ~2/hour.

In one accelerator component UFOs were traced to Aluminum oxide particles.









Timescales @ LHC






CERN

Incidents happen




JPARC home page – October 2013







JPARC incident – May 2013




- □ Due to a power converter failure, a slow extraction was transformed into a fast extraction.
 - Extraction in milliseconds instead of seconds.
- □ As a consequence of the high peak power a target was damaged and radio-isotopes were released into experimental halls.
 - >> machine protection coupled to personnel protection!
- Investigations and protection improvements are ongoing to allow JPAC to restart.

One insufficiently covered failure case had major consequences!


7 Nov 2013

Summary



Machine protection:

- requires a comprehensive overview of all aspects of the accelerator (accelerator physics, operation, equipment, instrumentation),
- requires understanding the different failure types that could lead to uncontrolled beam loss,
- affects many aspects of accelerator construction and operation,
- must be an integral part of the machine design,
- is becoming increasingly important for future projects, with increased beam power / energy density and increasingly complex machines.



Stored energies – the future



