

Beam Instrumentation and Diagnostics (Lecture 1)

CAS 2017

Royal Holloway, London

4th – 15th September, 2017

Dr. Rhodri Jones

Head of the CERN Beam Instrumentation Group



Introduction

- What do we mean by beam instrumentation?
 - The “eyes” of the machine operators
 - i.e. the instruments that observe beam behaviour
 - An accelerator can never be better than the instruments measuring its performance!
- What does work in beam instrumentation entail?
 - Design, construction & operation of instruments to observe particle beams
 - R&D to find new or improve existing techniques to fulfill new requirements
 - A combination of the following disciplines
 - Applied & Accelerator Physics; Mechanical, Electronic & Software Engineering
- What beam parameters do we measure?
 - Beam Position
 - Horizontal and vertical throughout the accelerator
 - At a specific location for tune, coupling & chromaticity measurements
 - Beam Intensity (& lifetime measurement for a storage ring/collider)
 - Bunch-by-bunch charge and total circulating current
 - Beam Loss
 - Especially important for high brightness and superconducting machines
 - Beam profiles
 - Transverse and longitudinal distribution



What is meant by Beam Diagnostics?

- Beam Diagnostics
 - Making use of beam instrumentation
- What do we consider as beam diagnostics?
 - Operating the accelerators
 - Using instrumentation to measure and correct standard parameters
 - Orbit, tune, chromaticity control etc.
 - Improving the performance of the accelerators
 - Understanding current performance to allow future improvements
 - Requires the measurement of performance indicators
 - Luminosity, brilliance (intensity and size) etc.
 - Understanding accelerator limitations
 - Beam loss, instabilities, emittance growth etc.
 - Detecting equipment faults
 - Aperture restrictions, polarity inversions, wrong settings etc.


Dr. Rhodri Jones – CERN Beam Instrumentation Group

Beam Instrumentation and Diagnostics - CAS 2017



How do we Qualify Beam Measurements?


- Accuracy, Precision, Resolution
 - Very often confused in day-to-day language
 - Accuracy – also known as the trueness of a measurement
 - Precision – how well a measurement can be reproduced
 - Resolution – the smallest possible difference measureable



- Example for a BPM
 - Mechanical & electrical offsets and gain factors influence accuracy
 - Various noise sources or timing jitter influence the precision
 - Number of bits in the ADC will limit the resolution

Dr. Rhodri Jones – CERN Beam Instrumentation Group

Beam Instrumentation and Diagnostics - CAS 2017



Beam Position Systems


Dr. Rhodri Jones – CERN Beam Instrumentation Group

Beam Instrumentation and Diagnostics - CAS 2017




Electromagnetic Fields & Relativity


Static Point Charge



Moving Point Charge



Relativistic Point Charge




- For highly relativistic particles
 - Electric & magnetic fields transverse to the direction of motion
 - Can be considered as a Transverse EM (TEM) wave
- For non-relativistic particles
 - Need to take into account the finite longitudinal extent of the EM field

Dr. Rhodri Jones – CERN Beam Instrumentation Group

Beam Instrumentation and Diagnostics - CAS 2017



Wall Current Monitor – The Principle




Dr. Rhodri Jones – CERN Beam Instrumentation Group

Beam Instrumentation and Diagnostics - CAS 2017



Wall Current Monitor – Beam Response




Dr. Rhodri Jones – CERN Beam Instrumentation Group

Beam Instrumentation and Diagnostics - CAS 2017



Electrostatic Monitor – The Principle




Dr. Rhodri Jones – CERN Beam Instrumentation Group

Beam Instrumentation and Diagnostics - CAS 2017



Electrostatic Monitor – Beam Response




Dr. Rhodri Jones – CERN Beam Instrumentation Group

Beam Instrumentation and Diagnostics - CAS 2017



Electrostatic Monitor – The Principle



Dr. Rhodri Jones – CERN Beam Instrumentation Group

Beam Instrumentation and Diagnostics - CAS 2017



Electrostatic Pick-up – Button

- ✓ Low cost \Rightarrow most popular
- ✗ Non-linear
 - requires correction algorithm when beam is off-centre



For Button with Capacitance C_e & Characteristic Impedance R_0

Transfer Impedance:

$$Z_{T(f \gg f_c)} = \frac{A}{(2\pi r) \times c \times C_e}$$

Lower Corner Frequency:

$$f_L = \frac{1}{2\pi R_0 C_e}$$



$$X = 2.30 \cdot 10^{-5} X_1^5 + 3.70 \cdot 10^{-5} X_1^3 + 1.035 X_1 + 7.53 \cdot 10^{-6} X_1^3 Y_1^2 + 1.53 \cdot 10^{-5} X_1 Y_1^4$$


Dr. Rhodri Jones – CERN Beam Instrumentation Group

Beam Instrumentation and Diagnostics - CAS 2017



Normalising the Position Reading

- To make it independent of intensity
- 3 main methods:
 - Difference/Sum : $(V_A - V_B) / (V_A + V_B) = \Delta / \Sigma$
 - Phase : $\text{Arctan}(V_A / V_B)$
 - Logarithm : $\text{Log}(V_A) - \text{Log}(V_B) = \frac{\text{Log}(V_A)}{\text{Log}(V_B)}$




Dr. Rhodri Jones – CERN Beam Instrumentation Group

Beam Instrumentation and Diagnostics - CAS 2017



Improving Precision for Next Generation Accelerators

- BPM electrodes typically give “intensity signals” with some position dependence!
 - Need to remove intensity content to get to the position
 - Difficult to do electronically without some intensity information leaking through
 - When looking for small differences this leakage can dominate the measurement
- Solution – cavity BPM allowing sub micron resolution
 - Design the detector to collect only the difference signal
 - Dipole Mode TM_{11} proportional to POSITION OFFSET (& intensity)
 - Shifted in frequency with respect to intensity dependent Monopole Mode TM_{01}




Dr. Rhodri Jones – CERN Beam Instrumentation Group

Beam Instrumentation and Diagnostics - CAS 2017



Cavity Beam Position Monitors



Monopole Mode

Obtain signal using waveguides that only couple to dipole mode for further Monopole Suppression

Dipole Mode

Type: E-field (peak)
Monitor: e-field (± 0.85 [pic])
Component: Normal
Maximum-Sd: 1.17208e+007 Hz at -3.5 / 3.5 / 8
Frequency: 3.88
Phase: 8 degrees

Type: E-field (peak)
Monitor: e-field (± 0.85 [pic])
Component: Normal
Maximum-Sd: 1.17208e+007 Hz at 8 / 2 / 8
Frequency: 5.65
Phase: 8 degrees

Dr. Rhodri Jones – CERN Beam Instrumentation Group



Beam Instrumentation and Diagnostics - CAS 2017



Today's State of the Art BPMs

- Prototype BPM for ILC Final Focus
 - Required resolution of 2nm (yes nano!) in a 6×12 mm diameter beam pipe
 - Achieved World Record (so far!) resolution of 8.7nm at ATF2 (KEK, Japan)

Courtesy of D. Lipka & Y. Honda




Dr. Rhodri Jones – CERN Beam Instrumentation Group

Beam Instrumentation and Diagnostics - CAS 2017



Comparison of BPM Resolution

- XFEL Data from 2017 Commissioning
 - Standard Button BPMs : 78 mm & 40.5 mm aperture (RED)
 - Re-entrant cavity BPMs : 78 mm aperture (GREEN)
 - Cavity BPMs : 40.5 mm and 10 mm aperture (BLUE)




Dr. Rhodri Jones – CERN Beam Instrumentation Group

Beam Instrumentation and Diagnostics - CAS 2017



Processing System Families





Dr. Rhodri Jones – CERN Beam Instrumentation Group

Beam Instrumentation and Diagnostics - CAS 2017



Modern BPM Read-out Electronics

- Based on the individual treatment of the electrode signals
 - Use of frequency domain signal processing techniques
 - Developed for telecommunications market
 - Rely on high frequency & high resolution analogue to digital converters
 - Minimising analogue circuitry
 - Frequency down-conversion used if necessary to adapt to ADC sampling rate
 - All further processing carried out in the subsequent digital electronics



Diagnostics using Beam Position Systems



Orbit or Trajectory Acquisition

- Main use of BPM systems
 - Measure & correct orbit or trajectory




Orbit excursion too large \Rightarrow need to correct

Dr. Rhodri Jones – CERN Beam Instrumentation Group

Beam Instrumentation and Diagnostics - CAS 2017



Orbit or Trajectory Correction




Dr. Rhodri Jones – CERN Beam Instrumentation Group

Beam Instrumentation and Diagnostics - CAS 2017




Initial Commissioning

- Threading the first pilot bunch round the LHC
 - One beam at a time, one hour per beam
 - Collimators used to intercept the beam
 - Correct trajectory, open collimator and move on




The Machine β -Function





Analysis of BPM Data

- On line analysis of BPM Data
 - Polarity errors easily identified with 45° BPM sampling
 - Quick indication of phase advance errors
 - Used to verify optics functions
 - e.g. matching from transfer lines into ring



Optics phase error

BPM polarity error


Dr. Rhodri Jones – CERN Beam Instrumentation Group

Beam Instrumentation and Diagnostics - CAS 2017



Machine Optics Measurements

- Light Sources
 - Dominated by closed orbit techniques (Orbit Response Matrix - e.g. LOCO)
 - Activate one orbit corrector & observe change in orbit
 - SOLEIL & DIAMOND achieved 0.3 - 0.4% β -beating
 - Recently improved BPM electronics
 - Now allows turn-by-turn techniques to start competing with orbit response
- LHC
 - Only turn-by-turn technique feasible with correction < 2% achievable




Dr. Rhodri Jones – CERN Beam Instrumentation Group

Beam Instrumentation and Diagnostics - CAS 2017




Maintaining Orbit Stability

- Earth Tides dominate during LHC Physics




$$\frac{\Delta a}{a} = + \frac{m a^3}{2 M R^3} (3 \cos^2 \psi - 1)$$



Dr. Rhodri Jones – CERN Beam Instrumentation Group

Beam Instrumentation and Diagnostics - CAS 2017




Beam Intensity Monitors

Dr. Rhodri Jones – CERN Beam Instrumentation Group

Beam Instrumentation and Diagnostics - CAS 2017



AC (Fast) Current Transformers




Dr. Rhodri Jones – CERN Beam Instrumentation Group

Beam Instrumentation and Diagnostics - CAS 2017



AC (Fast) Current Transformers




Dr. Rhodri Jones – CERN Beam Instrumentation Group

Beam Instrumentation and Diagnostics - CAS 2017



AC (Fast) Transformer Response

- Low cut-off
 - Impedance of secondary winding decreases at low frequency
 - Results in signal droop and baseline shift
 - Mitigated by baseline restoration techniques (analogue or digital)




Dr. Rhodri Jones – CERN Beam Instrumentation Group

Beam Instrumentation and Diagnostics - CAS 2017



The DC transformer

- AC transformers can be extended to very low frequency but not to DC (no di/dt !)
- DC measurement is required in storage rings
- To do this:
 - Take advantage of non-linear magnetisation curve
 - Use 2 identical cores modulated with opposite polarities




Dr. Rhodri Jones – CERN Beam Instrumentation Group

Beam Instrumentation and Diagnostics - CAS 2017



DCCT Principle – Case 1: no beam

Hysteresis loop
of modulator cores




Dr. Rhodri Jones – CERN Beam Instrumentation Group

Beam Instrumentation and Diagnostics - CAS 2017





DCCT Principle – Case 1: no beam


$$V \propto \frac{dB}{dt}$$



Dr. Rhodri Jones – CERN Beam Instrumentation Group

Beam Instrumentation and Diagnostics - CAS 2017





Diagnostics using Beam Intensity Monitors


Dr. Rhodri Jones – CERN Beam Instrumentation Group

Beam Instrumentation and Diagnostics - CAS 2017



BCTs in Operation

- Provide the general visual diagnostics for most accelerators
- LHC Operation Pages
 - Total intensity measurement
 - Lifetime calculation




Dr. Rhodri Jones – CERN Beam Instrumentation Group

Beam Instrumentation and Diagnostics - CAS 2017



Diagnostics using Fact BCTs



Bad RF Capture of a single LHC Batch in the SPS (72 bunches)

Dr. Rhodri Jones – CERN Beam Instrumentation Group

Beam Instrumentation and Diagnostics - CAS 2017



Beam Loss Monitors

Dr. Rhodri Jones – CERN Beam Instrumentation Group


Beam Instrumentation and Diagnostics - CAS 2017



Beam Loss Detectors

- Role of a BLM system:
 - Protect the machine from damage
 - Dump the beam to avoid magnet quenches (for SC magnets)
 - Diagnostic tool to improve the performance of the accelerator
- E.g. LHC

Stored Energy		Quench and Damage at 7 TeV	
Beam 7 TeV	2 x 362 MJ	Quench level	$\approx 1 \text{ mJ/cm}^3$
2011 Beam 3.5 TeV	above 2 x 100 MJ	Damage level	$\approx 1 \text{ J/cm}^3$



- SPS incident
 - June 2008
 - 2 MJ beam lost at 400 GeV


Dr. Rhodri Jones – CERN Beam Instrumentation Group

Beam Instrumentation and Diagnostics - CAS 2017



Beam Loss Detectors

- Common types of monitor
 - Long ionisation chamber (charge detection)
 - Up to several km of gas filled hollow coaxial cables
 - Position sensitivity achieved by comparing direct & reflected pulse
 - e.g. SLAC – 8m position resolution (30ns) over 3.5km cable length
 - Dynamic range of up to 10^4
 - Fibre optic monitors
 - Electrical signals replaced by light produced through Cerenkov effect





Dr. Rhodri Jones – CERN Beam Instrumentation Group

Beam Instrumentation and Diagnostics - CAS 2017



Beam Loss Detectors

- Common types of monitor
 - Ionisation chambers
 - Dynamic range of $< 10^8$
 - Slow response (μs) due to ion drift time





Dr. Rhodri Jones – CERN Beam Instrumentation Group

Beam Instrumentation and Diagnostics - CAS 2017



Beam Loss Detectors

- Common types of monitor
 - PIN photodiode (solid state ionisation chamber)
 - Detect coincidence of ionising particle crossing photodiodes
 - Count rate proportional to beam loss with speed limited by integration time
 - Can distinguish between X-rays & ionising particles
 - Dynamic range of up to 10^9





Dr. Rhodri Jones – CERN Beam Instrumentation Group

Beam Instrumentation and Diagnostics - CAS 2017



Beam Loss Detectors – New Materials

- Diamond Detectors
 - Fast & sensitive
 - Used in LHC to distinguish bunch by bunch losses
 - Investigations now ongoing to see if they can work in cryogenic conditions



Courtesy of E. Griesmayer

Dr. Rhodri Jones – CERN Beam Instrumentation Group

Beam Instrumentation and Diagnostics - CAS 2017



Diagnostics using Beam Loss Monitors


Dr. Rhodri Jones – CERN Beam Instrumentation Group

Beam Instrumentation and Diagnostics - CAS 2017



Recent Example from LHC

- Beam continually lost due to losses
 - What is going on?



Dr. Rhodri Jones – CERN Beam Instrumentation Group


Beam Instrumentation and Diagnostics - CAS 2017




BLM Diagnostics

- Localisation
 - BLM Spatial patterns clearly show losses originate from one specific interconnection
 - MQ16L2 (Cell 16 left of LHC Point 2)
 - Losses can be on either beam

Spatial BLM patterns for dumps@6.5 TeV on B1:



Spatial BLM patterns for dumps@6.5 TeV on B2:




Dr. Rhodri Jones – CERN Beam Instrumentation Group

Beam Instrumentation and Diagnostics - CAS 2017



BLM Diagnostics

- Time evolution





Dr. Rhodri Jones – CERN Beam Instrumentation Group

Beam Instrumentation and Diagnostics - CAS 2017



Other Diagnostics & Hypothesis

- Additional observations
 - Beam not always dumped by BLMs in 16L2
 - Often dumped by BLMs near primary collimators
 - Development of transverse instability visible on tune measurement system



- Current Hypothesis
 - Something went wrong during vacuum pumpdown
 - Air trapped on beam screen & cold bore of both beams
 - Solid nitrogen & oxygen formed
 - Falls into the beam & immediately vaporised
 - Creates local pressure rise
 - Leads to losses & beam instability

Dr. Rhodri Jones – CERN Beam Instrumentation Group

Beam Instrumentation and Diagnostics - CAS 2017



Summary of Lecture 1

- Today concentrated on beam position, intensity & loss monitors
 - Went into details of how they worked
 - Gave examples of their use as diagnostic tools
- Tomorrow we'll continue with a look at
 - Beam profile monitoring & diagnostics
 - Tune, Coupling & Chromaticity measurement & feedback

Want to know more?

Then Join the Beam Instrumentation Afternoon Course

- 3 Sessions on BPM design
 - Simulation software & “hands-on” laboratory measurements
- 1 Session on Tune Measurement
 - Program and measure using your own DSP
- 2 Sessions on Profile Measurements
 - “Hands-on” laboratory measurements
- Final Session
 - Group presentation of your BI proposals for an accelerator

