



Elettra Sincrotrone Trieste



Elettra
Sincrotrone
Trieste

Pulsing Kickers by Thyratrons at Elettra, 1990...2017 operations performance


Piergiorgio Tosolini

Head of the “Pulsers for Magnets” Laboratory




piergiorgio.tosolini@elettra.eu




Elettra Injection and Extraction



Elettra Injection main electrical ratings




0.5 kV 1.6kV
3 kA_{pk} 9kA_{pk}
SIB SEB
 SISR




Septa Pulsers

KEB: 12kV, 0.5kA
KIB : 5kV, 0.1kA



Booster Kickers Pulsers

12kV
6kA_{pk}
KISR





SR Kicker Pulsers

Every Pulse may be a story in itself

Was it requested or not, once started, Pulse is temporarily out of control and it develops according to the actual electrical situation.

If all conductors and insulators do their own duty, waveforms are as designed and expected.

If not, waveforms are distorted and some parts may be affected, *either reversibly or irreversibly.*



8 channel Oscilloscope KISR waveforms

At least one KISR3 and one KISR4 Pulses had insufficient amplitude

KISR4 trigger →

KISR3 trigger →

KISR2 trigger →

KISR1 trigger →

*Display mode:
infinite persistence*

KISR4 current →

KISR3 current →

KISR2 current →

KISR1 current →




All currents started after delay

➔ No self turn-on Pulses

Some KISR3 Pulses had nearly zero amplitude (little recharge or missing)

Magnet Current Pulse (effect)



Power Switch trigger (cause)


Simplified normal (i.e. following a valid trigger) Power Switch turn-on waveforms show that current into the magnet coil begins after a turn-on delay. Power Switch turn-on and turn-off cause some trigger waveform disturbs.

Real world measurements must take into account factors that affect signal integrity, such as ground loops and other conducted and radiated electromagnetic interference (EMI), cable delays, probes and attenuator factors, pickup circuits effects...



Power Switch self turn-on waveforms

Magnet Current Pulse (effect)



Missing requesting Power Switch trigger (no cause)

Simplified unrequested (i.e. with no requesting trigger) Power Switch waveforms show that current into the magnet coil starts apparently by itself (self turn-on). Switch turn-on and turn-off still cause some trigger waveform disturbs.

If the oscilloscope is synchronized on the magnet current rising edge, the absence of the previously requesting trigger pulse can be detected and the coil Pulse can be marked as false Injection Pulse.

Real waveforms are not so clean.

False Pulses: unrequested ones

Unrequested Pulses (i.e. Switch self turn-on) may occur caused by:

- 1) Too high anode voltage and/or its dv/dt
- 2) Enough conducted or radiated radiofrequency or radiation
- 3) Residual trigger pulse voltage and/or current and/or length
- 4) (for thyratrons) Inadequate heaters and/or grids bias ratings
- 5) Switch wear out, due to previous abuses and/or end-of-life
- 6) Too high temperature

Borderline triggers and self turn-on may damage Power Switches



Size, ...pardon..., Ratings Do Matter




2.4GeV
12kV
6kApk
2pps

2007..now: 2..2.4GeV
topup injection
E2V CX1573
1.7year quartet life
≈21k€/year
End-of-life due to
unwanted pulse
rate increase

2GeV
10kV
5kApk
2pps


1GeV
6kV
3kApk
10pps



1993..2007
E2V CX1154
quartet
10year life
<3k€/year
End-of-life
due to jitter


Storage Ring Kickers Thyatron
story, lifetimes and annual costs

- ✓ It is unpractical to stop present Pulse: Injection Diagnostics can only decide either to proceed towards next pulse or preventing it.
- ✓ If further faulty pulses are prevented, the relevant failure may be faced before worse (long-lasting...irreversible...) damages occur.
- ✓ Injection Equipment design emphasize testability for diagnostics and modularity for fast recovery of Machine Operations.



*Example: SR Inj Septum 2 Coil Earth Current **Waveform Mask Interlock**. If its waveform (mid, blue one) exits allowed mask (black area between top and bottom blue filled areas), the oscilloscope stores it, warns or even stops Pulser Charge, so reducing further coil insulation damages.*

Injection Control Equipment



Provisional Oscilloscopes, monitor Pulse and surrounding waveforms. They can interlock Pulser trigger and/or its High Voltage Recharge to protect equipment, perform vacuum conditioning, search for circuit working limits...

Injection Equipment is tendentially modular and standardized: a Magnetrol Unit, alone, may control either a Septum Solid State Pulser or...

...(passing cables through a Thyratrol Unit), may control a Thyatron based Kicker Pulser, adding relevant interlocks and functions to its basic ones: local/remote, HV recharge STOP/START, automatic or manual restart, vacuum interlock...


Adding further interlocks, controls...



Magnetrol implements Interlock bus logic, which allows to insert, remove, link more units together... sometimes without turnoff.



Mask, vacuum, temperature... interlocks may be easily added/removed, which helps automation in testing equipment, vacuum conditioning, fault finding, routine testing...

Most interlocks have selectors that allow to change relevant effects: BYP= ignore; REAL = self re-enable; MEM = manual re-enable.





Interlock bus layout examples



Example of six Units sharing control via a common Interlock bus

Injection Waveforms may be acquired and observed:

- One plant per oscilloscope, from the requiring trigger to its effects
- Same kind of signal from different Pulser plants

Their time scale depends on the actual detail of interest:

- Nanosecond to tens nanoseconds: jitter, delays, fast pulse edges
- Microsecond to tens microseconds: coil & earth current pulses
- Hundreds microseconds to tens milliseconds: thyatron bias recovery
- Hundreds milliseconds to seconds: charge delay, pulse repetition rate



- ✓ Injection Pulses cannot be controlled by human reaction times.
- ✓ Some fast actions may be done by automatic interlocks.
- ✓ **History:** a highly useful ability is to acquire, store and review **all Injection Pulses**, *specially bad ones*, with individual time stamps.

So the acquiring instrumentation (oscilloscopes) should have...

- 1. Minimum acquisition blind times** due to selfcalibrations, software updates, data transfers... *This helps the credibility of Injection monitoring, particularly when Injection is suspected for an undefined cause beam dump.*
- 2. Tightest time stamp accuracy and synchronization**, *possibly down to submillisecond resolution for realistic time stamps.*
- 3. Sufficient number of channels, bandwidth, sample rate, memory depth...**
- 4. History, Waveform mask pass/fail test output, OR trigger...**

Some Thyatron Pulsers design choices

- ✓ Keep power loop (magnet, PFN, power switch..) minimal and short
- ✓ Arrange star grounds so minimal currents normally pass there.
- ✓ Limit electrical ratings and their bandwidths in connections between control equipment (far from radiation area) and power loop.
- ✓ Keep circuitry simple, mechanically and electrically robust.
- ✓ Slow logic is electromechanical, earthed 48VAC, mains frequency.
- ✓ Thyatron filaments and reservoirs are individually filtered and clamped, AC driven via shielded transformers with primary Variac.
- ✓ Thyatron DC supplies are also individually remotely adjustable.
- ✓ Static insulating ferroresonant regulators stabilize and filter mains.
- ✓ Fast logic signals travel via fiber optics far from radiation area, and are converted in fast edges 400V / 50ohm thyatron drive pulses. Individual attenuated pickups allow thyatron switching monitoring.

Elettra Injection experience summary

- ✓ Following last Westcode Thyristor type refining (2007), Septa Pulsers troublelessly run with minimal preventive maintenance.
- ✓ After few years of 2..2.4GeV topup operations, SR Kicker Thyratrons suddenly began to erratically self turn on. The first documented Kicker beamdump was on 28 jan 2012. Since then, significant equipment and effort has been devoted to reduce Kicker beamdump rate, initially by more frequent thyatron replacement, then via bias and filaments adjust, migration to E2V CX1573, introduction of delayed restart of charge after a pulse, anode filtering... Till now about 100 Kicker Beamdumps occurred.
- ✓ Same Thyratrons in Booster have longer lifetime (>5 years)

Devil is in the details: where applicable, DIY approach pays.

Elettra Injection: Work in Progress

✓ Main goals:

- Minimization of residual Kicker Beam Dumps
- Lifetime extension of Storage Ring Kickers Thyratrons
- Reduction of Earth Fault Coil Current in Septa Pulsers
- Development / Evaluation of Kicker Solid State Pulsers

✓ Main activities:

- Hunting progress to discover Kicker Beam Dump smoking gun
- Improvements in measurements of Thyatron parameters
- Development of a Storage Ring Kicker Common Supervisor
- Extended lab tests of Septa and Kicker Pulsers for Elettra 2
- Extended Beam-environment tests of dummy Pulser prototypes



Elettra
Sincrotrone
Trieste

Thank you. Any question?




www.elettra.eu



Elettra
Sincrotrone
Trieste

Accelerators of Elettra




1994 – 2007:

Elettra Storage Ring came into operation in 1994, being the first third generation light source for soft-X rays in Europe.

Initially max. energy 2 GeV, currently operating either at 2.0 GeV and 2.4 GeV

As injector used a linac (no full energy injection)



Since 2011:

4th Generation light source

Since 2008:

Full energy injector (linac + booster) at 2.0 & 2.4 GeV

Since 2010:


Regular TopUp operations during Users' beam time

Built WITHOUT affecting Elettra operations!







Booster Injection Layout



Booster Extraction Layout




Elettra Storage Ring Injection Layout






Elettra
Sincrotrone
Trieste

KISR1 Pulser (cover is removed)






Artisan KISR coil HV insulation test set







KISR Waveforms History





Signal Integrity Issues may fool Analysis




Uncorrect terminations on remote ($\approx 150\text{m}$ coaxial cable) oscilloscopes may suggest unreal faults on working Pulsers





Elettra
Sincrotrone
Trieste

Storage Ring Septa Vacuum Tank (open)



Storage Ring Kickers Ceramic Chambers




3 μm thick Titanium sputtering:
endoscope did not evidence any
serious wear after 14 years use

Elettra Injection (and Extraction) Pulsers


All Elettra Injection and Extraction Magnets Pulsers employ latching type Power Switches: Thyristor for Septa and Thyatron for Kickers.



bare
Power
Switches



Power
Switches
installed
in relevant
Pulsers




Injection Magnet Pulser configuration

It is impractical to take such high ratings in real time from mains.

A Pulser circuit is placed close to each Magnet coil. It hosts:

- 1) a **Pulse Forming Network** (Capacitors, Inductors, Cables...) where energy is gradually stored by a Charger Power Supply
- 2) a Power Switch between PFN and coil. Its own resistance is:
 - (Charge) High, so disconnecting coil, allowing PFN charge
 - (Pulse) Low, so connecting coil, when trigger commands coil Pulse



Wanted and Unwanted Injection Pulses

Latching type Power Switches (either Solid State Semiconductor Thyristor or Deuterium Tube Thyatron), in apparently normal conditions, *may sometimes not obey to relevant trigger commands:*

1) Missing a wanted Pulse (remaining open) after a valid trigger

2) Producing an unrequested Pulse (**closing**) with no trigger received.

According to Machine status, the mispulsed Magnet role, its timing and involved ratings, the consequent missing or unwanted particle deflecting Pulse may partially disturb or totally kill the stored beam.

Even few false KISR Pulses per million good ones do molest.


Latching type Power Switches

Once **closed** into conduction for any reason, wanted or not, a latching Switch does not accept any command to **open**.

The Switch opens by itself only after its current stays under a certain value for a while (recovery time). This is usually provided by suitable Pulse waveform design and/or by temporary stop and appropriately delayed restart of charge.

Magnet Current Pulse

*Before Pulse,
Switch was
open = not
conducting*



Recovery time to
cease conduction

*After recovery
time, Switch
returns not
conducting*

Pulse and some time after:
Switch is closed = conducting

False Pulses: missing ones

According to Power Switch physics and actual surrounding conditions, some of the *reasons for a missing Pulse may be:*

- 1) Anode voltage too low (ex: polarity reversed) to correctly turn-on
- 2) Insufficient trigger pulse length
- 3) Insufficient trigger pulse current and/or voltage
- 4) (for thyratrons) Inadequate heaters and/or grids bias ratings
- 5) Too low temperature