

Multipacting

Renzo Parodi

INFN-Genova

Basic facts

- Multipacting is a Resonant Electron Discharge with Electron Multiplication.
- To have multipacting you need the occurrence of two conditions
 - 1) *electron synchronization with the RF Field.*
 - 2) *Electron multiplication via Secondary electron reemission.*

electron synchronization with the RF Field.

- The time between two electron impacts on the cavity wall is \sim an integer number of half RF cycles.
- This condition forces the starting condition for the electrons reemitted at each impact to be always the same

Electron multiplication via secondaries


- This condition set the mechanism for a runaway discharge depleting the energy stored in the cavity.
- The Secondary emission coefficient δ need to be >1 . (even slightly)
- To fulfil this multiplication condition the impact energy U of the electrons is usually in the range 50~1500 eV (for metals)
- Secondary emitted electron Energy $\sim 2\text{eV}$

Unfortunately

- Good metallic conductors used for RF accelerating structures (Copper, Silver and Niobium) already have δ greater than ONE!
- Titanium, Stainless steel have δ lower than one
- The Secondary Emission Coefficient strongly depends on the surface conditions (oxidation increases δ , carbon layers decreases)

Secondary Emission Coefficient

Secondary Emission Coefficient



Two Point MP

- Occurs when electrons impacts cavity regions with fields of opposite sign
- Synchronization is obtained for time of flight ~ an integer number of Half RF cycles.
- Multiplication is achieved if the impact energy is in the range 50 to 1500 eV

All the following discussion is valid ONLY for axial-symmetric accelerating RF structures with NO static Magnetic Field superimposed

Look what happens adding .3 Tesla Field along Z

QuickTime™ and a decompressor are needed to see this picture.


QuickTime™ and a decompressor are needed to see this picture.

- A typical example is MP in short gap Cavities as:
- low beta cavities (heavy ions, buncher, catcher)
- semi lumped cavities like to one used in the old time storage rings as ADONE.
- Approximating (if possible) the gap with a parallel plate capacitor it is possible to analytically solve the motion equation and obtain a reasonable guess of the MP discharge field.

RF capacitor MP discharge

Starting condition

- 1) An electron starts at rest on the capacitor plate
- 2) The electron strikes the opposite plate after an integer number of half RF Cycles.



- Solving the motion equations (C.Kittel, Berkley Physics Course Vol.1 pag102, McGraw-Hill) and imposing the starting condition we get the value for the gap voltage at the n^{th} resonance

$$E \times L = V = 4 * \pi * m_0 * c^2 * (L/\lambda)^2 * 1/(2n-1)$$

- And the corresponding value for the impact energy

$$U = 8 * m_0 * c^2 * (L/\lambda)^2 * 1/(2n-1)^2$$

One Point MP

- Occurs when electrons impacts cavity allways in the same place
- Synchronization is obtained for time of flight ~ an integer number of RF periods.
- Multiplication is again achieved if the impact energy is in the range 50 to 1500 eV


- In Axial-Symmetric accelerating TM_{01} cavities this resonant discharge happens at the equatorial region where the magnetic field is high (and the electric field is quite low).
- The secondary electrons are trapped by the strong magnetic field in a Cyclotron-like orbit. Landing fairly in the takeoff place after an integral number of RF Cycles.
- The energy gain due to the electric field is quite low, (the electric field in a pure Pill_Box accelerating cavity is ZERO at the equator.) and gives the right amount of energy 50-1500eV leading to multiplication via secondary emission.

Although for this particular kind of MP discharge no simplified analytical model is possible, nevertheless a POOR MAN estimation is possible for the kinematic condition.

- *Let consider the motion of the electron in a sinusoidal RF magnetic field .*
- *the trajectories are roughly cyclotron orbits and the synchronus motion condition is given by the approximated expression:*

$$\frac{f}{N} = \frac{eB_0}{2\pi m_0}$$

**This gives us 28 mT per GHz
for the Highest level using a
first order correction for the
effective field seen by the
flying electron**




Last, at the cavity equator is still possible a 2 point discharge with the electrons flying across the cavity mid_plane

$$\frac{f}{(2N - 1)} = \frac{eB_0}{2\pi m_0}$$

- **This gives us 56 mT per GHz for the Highest level using the usual first order correction for the effective field seen by the flying electron**

TRAJECTORIES #
EMAX= 52.496 MV/M BMAX= 961.832 GAUSS




- For all the MP discharge at the equator the Poor Man Rules give only an Hint about the field levels to loog at for MP related problems.
- The full detail can only be found numerically by solving the motion equation in the real geometry, using a detailed and realistic implementation of the reemission process.
- Any way computer simulations and experimental measurement have shown the reliability of the POOR MAN estimation for MP barriers.

Electron Yield in a 1.4Ghz cavity

(computer simulation)

B field (Gauss)

From synchronization
condition



Level order	MP 1pt	MP 2pt
1	392	784
2	196	261
3	131	157
4	98	112

How to avoid MP
discharges?

Reduce Electron multiplication

- **Use materials with a low secondary yield to avoid electron multiplication.**

Unfortunately good conductors and superconductors have Secondary Yields > 1

- **Use thin coating ($d \ll$ of the skin depth) of low secondary Yield materials in the critical regions of the accelerating structures.**

Avoid spatial focusing of the electrons in critical regions.

- This was done in SRF cavities choosing the rounded shape in the equator region in the late seventies (see IEEE Trans on Magnetics, Mag-15.pag.25 January 1979)
- With this trick we always have a force (due to the E_z component of the field on the cavity surface) seeping the reemitted electrons away from the emission point.
- Only at the equator the E_z is ZERO, as the E_r component and (if you are lucky) the electrons lose the synchronization with the RF field and the discharge stop.

QuickTime™ and a
decompressor
are needed to see this picture.