


# Beam Diagnostics and Instrumentation

*JUAS 2020, Archamps*

Peter Forck

Gesellschaft für Schwerionenforschung (GSI) and University Frankfurt



**Diagnostics is the 'sensory organs' for the beam.**

**It deals with real beams in real technical installations including all imperfections.**

**Three types of demands lead to different installations:**

- Quick, non-destructive measurements leading to a single number or simple plots  
Used as a check for online information. Reliable technologies have to be used  
**Example:** Current measurement by transformers
- Instruments for daily check, malfunction diagnosis and wanted parameter variation  
**Example:** Profile measurement, in many cases 'intercepting' i.e destructive to the beam
- Complex instruments for severe malfunctions, accelerator commissioning & development  
The instrumentation might be destructive and complex  
**Example:** Emittance determination

**General usage of beam instrumentation:**

- Monitoring of beam parameters for operation, beam alignment, acc. development.....
- Instruments for automatic, active beam control  
**Example:** Closed orbit feedback using position measurement by BPMs

**Non-destructive ('non-intercepting') methods are preferred:**


- The beam is not influenced
- The instrument is not destroyed

# The Role of Beam Diagnostics


The cost of diagnostics is about 3 to 10 % of the total facility cost:

- $\approx 3\%$  for large accelerators *or* accelerators with standard technologies
- $\approx 10\%$  for versatile accelerators *or* novel accelerators and technologies.

## Cost Examples: Proton LINAC



## Super-conducting synchr.



The amount of man-power is about 10 to 20 %:

- very different physics and technologies are applied
- technologies have to be up-graded, e.g. data acquisition and analysis
- accelerator improvement calls for new diagnostic concepts.

# Relevant physical Processes for Beam Diagnostics

- **Electro-magnetic influence by moving charges:**
    - **Physics:** classical electro-dynamics. **Technique:**  $U$  and  $I$  meas., low & high frequencies
    - Examples:** Faraday cups, beam transformers, pick-ups
  - **Emission of photon by accelerated charges: (only for high relativistic electrons and p)**
    - **Physics:** classical electro-dynamics. **Technique:** optical techniques (from visible to x-ray)
    - Example:** Synchrotron radiation monitors
  - **Interaction of particles with photons:**
    - **Physics:** optics, lasers. **Technique:** optical techniques, particle detectors
    - Examples:** laser scanners, short bunch length measurement, polarimeters
  - **Coulomb interaction of charged particles with matter:**
    - **Physics:** atomic and solid state physics. **Technique:**  $I$  meas., optics, particle detectors
    - Examples:** scintillators, viewing screens, ionization chambers, residual gas monitors
  - **Nuclear- or elementary particle physics interactions:**
    - **Physics:** nuclear physics. **Technique:** particle detectors
    - Examples:** beam loss monitors, polarimeters, luminosity monitors
  - **And of course accelerator physics for proper instrumentation layout.**
- Beam diagnostics deals with the full spectrum of physics and technology,  
 ⇒ this calls for experts on all these fields and is a challenging task!**

**LINAC & transport lines:** single pass  $\leftrightarrow$  **Synchrotron:** multi pass

**Electrons:** always relativistic  $\leftrightarrow$  **Protons/Ions:** non-relativistic for  $E_{kin} < 1 \text{ GeV/u}$

**Depending on application:** low current  $\leftrightarrow$  high current

**Overview of the most commonly used systems:**

Beam quantity		Transfer line	Synchrotron
Current $I$	<i>General</i>	Transformer, dc & ac Faraday Cup	Transformer, dc & ac
	<i>Special</i>	Particle Detectors	Pick-up Signal (relative)
Profile $x_{width}$	<i>General</i>	Screens, SEM-Grids Wire Scanners, OTR Screen	Ionization Profile Monitor Wire Scanner, Synchrotron Light Monitor
	<i>Special</i>	MWPC, Fluorescence Light	
Position $x_{cm}$	<i>General</i>	Pick-up (BPM)	Pick-up (BPM)
	<i>Special</i>	Using position measurement	
Transverse Emittance $\epsilon_{trans}$	<i>General</i>	Slit-grid Quadrupole Variation	Ionization Profile Monitor Wire Scanner
	<i>Special</i>	Pepper-Pot	Transverse Schottky


# Beam Quantities and their Diagnostics II

Beam quantity		Transfer line	Synchrotron
Bunch Length $\Delta\varphi$	<i>General</i>	Pick-up	Pick-up Wall Current Monitor
	<i>Special</i>	Secondary electrons arrival Electro-optical laser mod.	Streak Camera Electro-optical laser mod.
Momentum $p$ and Momentum Spread $\Delta p/p$	<i>General</i>	Pick-ups (Time-of-Flight)	Pick-up (e.g. tomography)
	<i>Special</i>	Magnetic Spectrometer	Schottky Noise Spectrum
Longitudinal Emittance $\varepsilon_{long}$	<i>General</i>	Buncher variation	Pick-up & tomography
	<i>Special</i>	Magnetic Spectrometer	
Tune and Chromaticity $Q, \xi$	<i>General</i>	---	Exciter + Pick-up
	<i>Special</i>	---	Transverse Schottky Spectrum
Beam Loss $r_{loss}$	<i>General</i>	Particle Detectors	
Polarization $P$	<i>General</i>	Particle Detectors	
	<i>Special</i>	Laser Scattering (Compton scattering)	
Luminosity $L$	<i>General</i>	Particle Detectors	


- Destructive and non-destructive devices depending on the beam parameter.
- Different techniques for the same quantity  $\leftrightarrow$  Same technique for the different quantities.

**Remark:** In most cases no diagnostics device installed inside the rf-cavities (except cyclotron)

# Example: Diagnostics Bench for the Commissioning of an RFQ




# Typical Installation of a Beam Instrument




- Accelerator tunnel:** {
- action of the beam to the detector
  - low noise pre-amplifier and first signal shaping
- Local electronics room:** {
- analog treatment, partly combining other parameters
  - digitalization, data bus systems (GPIB, VME, cPCI,  $\mu$ TCA...)



# Typical Installation of a Beam Instrument



- Accelerator tunnel:** {
  - action of the beam to the instrument
  - low noise pre-amplifier
- Local electronics room:** {
  - analog treatment, parameter setting
  - digitalization, data transfer
- Control room:** {
  - visualization and storage
  - parameter setting




# Close Orbit Measurement with Beam Position Monitors BPM

Single bunch position averaged over 1000 bunches → closed orbit with ms time steps.

It differs from ideal orbit by misalignments of the beam or components.

Example: GSI-synchrotron at two BPM locations, 1000 turn average during acceleration:



**Closed orbit:**

Beam position averaged over many turns (i.e. betatron oscillations).

The result helps to align the accelerator!

Some device parameters are shown to prove functionality.

## The ordering of the subjects is oriented by the beam quantities:

- **Current measurement:** Transformers, cups, particle detectors
- **Profile measurement:** Various methods depending on the beam properties
- **Transverse emittance measurement:** Destructive devices, determination by linear transformations
- **Pick-ups for bunched beams:** Principle and realization of rf pick-ups, closed orbit and tune measurements
- **Measurement of longitudinal parameters:** Beam energy with pick-ups, time structure of bunches for low and high beam energies, longitudinal emittance
- **Beam loss detection:** Secondary particle detection for optimization and protection

**It will be discussed:** The action of the beam to the detector, the design of the devices, generated raw data, partly analog electronics, results of the measurements.

**It will not be discussed:** Detailed signal-to-noise calculations, analog electronics, digital electronics, data acquisition and analysis, online and offline software....

**General:** Standard methods and equipment for stable beams with moderate intensities.

# Organization of the Lecture

## Lecture:

- Emittance
- Pick-up
- Longi. parameters

## Additionally on March 11:

Practical work at company Bergoz with beam current transformers

## Lecture:

- Overview
- Current

## Exercise

## Lecture:

- Transverse profile

## Lecture:


- Longi. parameters
- Beam loss det.

**Exercise & presentation:  
Your hard work!**

Schedule 2020	Monday Feb 24	Tuesday Feb 25	Wednesday Feb 26	Thursday Feb 27	Friday Feb 28
09:00	Beam instrumentation <i>P. Forck</i>	Beam instrumentation <i>P. Forck</i>	Beam instrumentation <i>P. Forck</i>	Bus leaves at 17:30 from CERN	CERN
10:00	Coffee Break	Coffee Break	Coffee Break		
10:15	Beam instrumentation <i>P. Forck</i>	Beam instrumentation <i>P. Forck</i>	Beam instrumentation <i>P. Forck</i>		
10:30	Beam instrumentation <i>P. Forck</i>	Beam instrumentation <i>P. Forck</i>	Beam instrumentation <i>P. Forck</i>	CERN	CERN
11:15	Beam instrumentation <i>P. Forck</i>	Beam instrumentation <i>P. Forck</i>	Beam instrumentation <i>P. Forck</i>		
12:15	WORKING LUNCH	BREAK	BREAK		
14:00	Beam instrumentation <i>P. Forck</i>	Beam instrumentation <i>P. Forck</i>	Beam instrumentation <i>P. Forck</i>	MAGNET coordinators: J. Bauche L. Fiscarelli	MAGNET coordinators: J. Bauche L. Fiscarelli
15:00	Superconducting RF Cavities <i>F. Caspers</i>	Superconducting RF Cavities <i>F. Caspers</i>	Superconducting RF Cavities <i>F. Caspers</i>		
16:00	Coffee Break	Coffee Break	Coffee Break		
16:15	Superconducting RF Cavities <i>F. Caspers</i>	Superconducting RF Cavities <i>F. Caspers</i>	Superconducting RF Cavities <i>F. Caspers</i>	SUPERCONDUCTIVITY coordinator: J. Fleiter	SUPERCONDUCTIVITY coordinator: J. Fleiter
17:15	Superconducting RF Cavities <i>F. Caspers</i>	Superconducting RF Cavities <i>F. Caspers</i>	Superconducting RF Cavities <i>F. Caspers</i>		
18:15			Building Large Accelerators Seminar <i>Ph. Lebrun</i>	CLEAR coordinators: R. Corsini W. Farabolini	CLEAR coordinators: R. Corsini W. Farabolini
			AFTER WORK AT ESI		

**General: Please ask questions & make comments → all interrupts are welcome!  
This is your event!**

# Goal of the Lecture



The goal of the lecture should be:

- Understanding the signal generation of various device
- Showing examples for real beam behavior
- Enabling a correct interpretation of various measurements.

## Backup slides